

[illegible]

[illegible]

TSDRIVER
Table of contents

N 2
- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00

Page 0

(1)	499	DRIVER TABLES
(1)	790	UNIT INITIALIZATION ROUTINE
(1)	935	TEST NBA (NEED BUFFER ADDRESS)
(1)	1034	START I/O OPERATION
(2)	1233	NOP AND SIMULATED FUNCTIONS
(2)	1268	READ HARDWARE FUNCTIONS
(2)	1353	WRITE FUNCTIONS
(2)	1420	POSITIONING FUNCTIONS
(2)	1563	FORMAT COMMANDS
(2)	1615	CONTROL COMMANDS
(2)	1641	INITIALIZE AND GET STATUS
(2)	1693	COMPLETION PROCESSING
(2)	1740	HARDWARE COMMAND EXECUTOR
(3)	2170	TS11/TS04 INTERRUPT SERVICE ROUTINE
(3)	2241	TIMEOUT HANDLER
(3)	2358	TS11/TS04 REGISTER DUMP ROUTINE


```
0000 1 .TITLE TSDRIVER - VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DRIVER
0000 2 .IDENT 'V04-000'
0000 3
0000 4
0000 5 *****
0000 6 *
0000 7 * COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
0000 8 * DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
0000 9 * ALL RIGHTS RESERVED.
0000 10 *
0000 11 * THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
0000 12 * ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
0000 13 * INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
0000 14 * COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
0000 15 * OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
0000 16 * TRANSFERRED.
0000 17 *
0000 18 * THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
0000 19 * AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
0000 20 * CORPORATION.
0000 21 *
0000 22 * DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
0000 23 * SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
0000 24 *
0000 25 *
0000 26 *****
0000 27
0000 28
0000 29 : E. E. OUYANG 2-APR-79
0000 30
0000 31 : MODIFIED BY:
0000 32
0000 33 : V03-017 MMD0317 Meg Dumont, 25-Jul-1984 11:13
0000 34 : Add support for the UCBSL_MEDIA_ID field
0000 35
0000 36 : V03-016 MMD0304 Meg Dumont, 27-Jun-1984 15:24
0000 37 : Fix to 296 so that only READ REVERSE into BOT returns ENDOFFILE
0000 38
0000 39 : V03-015 MMD0296 Meg Dumont, 3-May-1984 9:45
0000 40 : Fix to fix MMD0265 we really must return SS$_NORMAL not
0000 41 : anyother error code.
0000 42
0000 43 : V03-014 ROW0355 Ralph O. Weber 30-APR-1984
0000 44 : Modify processing of the IOSM_OPPOSITE modifier so that its
0000 45 : use is limited to IOS$_REREADN and IOS$_REREADP functions by
0000 46 : code, rather than by comments. This provides some protection
0000 47 : against accidental misuse of the IOSM_CLSEREXCP bit which is
0000 48 : relivant only for tape class driver tapes but which shares the
0000 49 : same modifier bit as IOSM_OPPOSITE.
0000 50
0000 51 : V03-013 RAS0300 Ron Schaefer 27-Apr-1984
0000 52 : Add DEV$_NNM characteristic to DECHAR2 so that these
0000 53 : devices will have the 'node$' prefix.
0000 54
0000 55 : V03-012 MMD0265 Meg Dumont, 22-Mar-1984 15:28
0000 56 : Fix so that reverse into BOT returns SS$_ENDOFFILE like other
0000 57 : drivers.
```



```
0000 58 :
0000 59 :
0000 60 : V03-011 MMD0225 Meg Dumont, 23-Jan-1984 11:27
0000 61 : Deleted the check in the drivers' unit init routine which
0000 62 : checked on powerfail to see if the TS SUBSYSTEM was ready
0000 63 : before reloading registers etc.. This check was no
0000 64 : longer necessary since Robert added the code TEST_NBA which
0000 65 : makes sure the controller is available before we allow
0000 66 : the QIO to start on the device.
0000 67 :
0000 68 : V03-010 MMD0219 Meg Dumont, 9-Jan-1984 13:59
0000 69 : Instead of checking for powerfail at TS_INIT check
0000 70 : for command buffer allocated. Fix for support of
0000 71 : switchable unibus
0000 72 :
0000 73 : V03-009 ROW0258 Ralph O. Weber 17-NOV-1983
0000 74 : The Paul Painter Memorial Enhancement
0000 75 : Named for one of the unfortunate customers who suffered much
0000 76 : to determine the great UCBSL_MT_RECORD secret while trying to
0000 77 : create a user-written magtape driver, this change eliminates
0000 78 : use of the device dependent field, UCBSL_MS_RECORD in favor of
0000 79 : the device independent field, UCBSL_RECORD.
0000 80 :
0000 81 : V03-008 ROW0213 Ralph O. Weber 20-AUG-1983
0000 82 : Change basing for device-dependent UCB from UCBSL_DP_LINK+4 to
0000 83 : a field independent UCBSK_LCL_TAPE_LENGTH. This allows the
0000 84 : device-independent UCB to be altered without having to edit
0000 85 : this module.
0000 86 :
0000 87 : V03-007 BLS0234 Benn Schreiber 9-Aug-1983
0000 88 : Use general addressing mode for EXESREAD_TODR.
0000 89 :
0000 90 : V03-006 KDM0060 Kathleen D. Morse 14-Jul-1983
0000 91 : Change references to IPR TODR to use cpu-dependent
0000 92 : routine, EXESREAD_TODR.
0000 93 :
0000 94 : V03-005 RLRDPATH1 Robert L. Rappaport 31-May-1983
0000 95 : Allow UCB to include new DUAL PORT extension by
0000 96 : changing base of where we begin the private TSDRIVER
0000 97 : extension from UCBSL_DPC+4 to UCBSL_DP_LINK+4.
0000 98 :
0000 99 : V03-004 RLRTRACE Robert L. Rappaport 11-Feb-1983
0000 100 : Add conditionally assembled trace facility.
0000 101 :
0000 102 : V03-003 RLR52135 Robert L. Rappaport 22-Dec-1982
0000 103 : Prevent reverse into BOT from returning SS$_OPINCOMPL.
0000 104 :
0000 105 : V03-002 RLR0001 Robert L. Rappaport 15-July-1982
0000 106 : Prevent logging two errors for each soft retry.
0000 107 :
0000 108 : V03-001 KDM0002 Kathleen D. Morse 28-Jun-1982
0000 109 : Added $DCDEF, $DEVDEF, $DYNDEF, $PRDEF and $VADEF.
0000 110 :
0000 111 : TS11/TS04 MAGTAPE DRIVER
0000 112 :
0000 113 : MACRO LIBRARY CALLS
0000 114 :
```



```
0000 115
0000 116      $CRBDEF      ;DEFINE CRB OFFSETS
0000 117      $DCDEF      ;DEFINE DEVICE TYPES
0000 118      $DDBDEF      ;DEFINE DDB OFFSETS
0000 119      $DEVDEF      ;DEFINE DEVICE TYPES
0000 120      $DPTDEF      ;DEFINE DPT OFFSETS
0000 121      $DYNDEF      ;DEFINE DYNAMIC DATA STRUCTURE TYPES
0000 122      $EMBDEF      ;DEFINE EMB OFFSETS
0000 123      $IDBDEF      ;DEFINE IDB OFFSETS
0000 124      $IODEF       ;DEFINE I/O FUNCTION CODES
0000 125      $IRPDEF      ;DEFINE IRP OFFSETS
0000 126      $MTDEF       ;DEFINE MAGTAPE STATUS BITS
0000 127      $PRDEF       ;DEFINE PROCESSOR REGISTERS
0000 128      $SSDEF       ;DEFINE QIO STATUS RETURN CODES
0000 129      $UCBDEF      ;DEFINE UCB OFFSETS
0000 130      $VADEF       ;DEFINE VIRTUAL ADDRESS FIELDS
0000 131      $VECDEF      ;DEFINE INTERRUPT DISPATCH VECTOR OFFSETS
0000 132      $WCBDEF      ;DEFINE WCB OFFSETS
0000 133
0000 134      :
0000 135      : LOCAL MACROS
0000 136      :
0000 137      : EXECUTE HARDWARE COMMAND AND BRANCH ON RETRIABLE ERROR CONDITION
0000 138      :
0000 139
0000 140      .MACRO EXHC      BDST,HC
0000 141      .IF NB      HC
0000 142      MOVZBL #CD'HC,RO      ;GET HARDWARE COMMAND INDEX
0000 143      .ENDC
0000 144      BSBW      HCEX      ;CALL HARDWARE COMMAND EXECUTION ROUTINE
0000 145      .WORD      BDST-.-2      ;BRANCH ADDR. ON ERROR CONDITION
0000 146      .ENDM      EXHC
0000 147
0000 148      ; MACRO TO CALL G^IOC$LOADUBAMAPA
0000 149
0000 150      .MACRO LOADUBAA
0000 151      JSB      G^IOC$LOADUBAMAPA
0000 152      .ENDM      LOADUBAA
0000 153
0000 154
0000 155      :
0000 156      : GENERATE HARDWARE COMMAND TABLE ENTRY AND CASE TABLE INDEX SYMBOL
0000 157      :
0000 158
0000 159      .MACRO GENHC      HC
0000 160      CD'HC=<.-HCTAB>/2      ;DEFINE TABLE INDEX SYMBOL
0000 161      .WORD      HC      ;HARDWARE COMMAND TABLE ENTRY
0000 162      .ENDM      GENHC
0000 163
0000 164
0000 165      :
0000 166      : LOCAL SYMBOLS
0000 167      :
0000 168      :
0000 169      : TS11/TS04 COMMAND PACKET DEFINITION
0000 170      :
0000 171      :
```



```
00000000 0000 172
0000 173
0000 174
0000 175
0000 176
0000 177 $DEF MS_CPHD .BLKW 1
0002 178 _VIELD MS_CPHD,0,<-
0002 179 <COD,5>,-
0002 180 <2>,-
0002 181 <IE,,M>,-
0002 182 <MOD,4>,-
0002 183
0002 184 <SWB,,M>,-
0002 185 <OPP,,M>,-
0002 186 <CVC,,M>,-
0002 187 <ACK,,M>,-
0002 188
0002 189 $DEF MS_BACT .BLKW 1
0004 190 $DEF MS_BA1 .BLKW 1
0006 191 $DEF MS_CNT .BLKW 1
0008 192
0008 193 $DEF MS_MBA0 .BLKW 1
000A 194 $DEF MS_MBA1 .BLKW 1
000C 195 $DEF MS_LNTH .BLKW 1
000E 196 $DEF MS_CHWD .BLKW 1
0010 197 _VIELD MS_CHWD,4,<-
0010 198 <ERI,,M>,-
0010 199 <EAI,,M>,-
0010 200 <ENB,,M>,-
0010 201 <ESS,,M>,-
0010 202
0010 203
0010 204
0010 205 : TS11/TS04 MESSAGE PACKET DEFINITION
0010 206 :
0010 207
0010 208
0010 209 $DEF MS_MHD .BLKW 1
0012 210 _VIELD MS_MHD,0,<-
0012 211 <COD,5>,-
0012 212 <FMT,3>,-
0012 213 <CLS,4>,-
0012 214 <RSR,3>,-
0012 215 <ACK,,M>,-
0012 216
0012 217 $DEF MS_LNH .BLKW 1
0014 218
0014 219 $DEF MS_RBPC .BLKW 1
0016 220 $DEF MS_XSRO .BLKW 1
0018 221 _VIELD MS_XSRO,0,<-
0018 222 <EOT,,M>,-
0018 223 <BOT,,M>,-
0018 224 <WLK,,M>,-
0018 225 <PED,,M>,-
0018 226 <VCK,,M>,-
0018 227 <IE,,M>,-
0018 228 <ONL,,M>,-

;RESET PC?????
;COMMAND PACKET HEADER
;
;COMMAND CODE FIELD
;B5-B6 ALWAYS 0 FOR TS04
;INTERRUPT ENABLE
;COMMAND MODE FIELD(B11-B8)
; B8=REVERSE & B9=RETRY
;SWAP BYTES BIT(B12)
;OPPOSITE BIT(B13)
;CLEAR VOLUME CHECK(B14)
;ACKNOWLEDGE BIT(B15)
;
;BUS ADDRESS(B15-B0) OR COUNT
;BUS ADDRESS B17-B16(RIGHT JUST)
;BYTE COUNT
;FOR WRITE CHARACTERISTIC DATA
;MESSAGE BUFFER ADDR. WRD 1
;MESSAGE BUFFER ADDR. WRD 2
;MESSAGE BUFFER LENGTH(ALWAYS 14.)
;CHARACTERISTIC WORD
;
;ENABLE MESSAGE BUFFER RELEASE INTERRUPTS
;ENABLE ATTENTION INTERRUPTS
;USED WITH ESS BIT***
;ENABLE SKIP TAPE MARKS STOP
```



```
0018 229 <MOT,,M>,- :TAPE MOVING ON LAST COMMAND(B7)
0018 230 <ILA,,M>,- :ILLEGAL ADDRESS(B8)
0018 231 <ILC,,M>,- :ILLEGAL COMMAND(B9)
0018 232 <NEF,,M>,- :NON-EXECUTABLE FUNCTION(B10)
0018 233 <WLE,,M>,- :WRITE LOCK ERROR(B11)
0018 234 <RLL,,M>,- :RECORD LENGTH LONG(B12)
0018 235 <LET,,M>,- :LOGICAL END OF TAPE(B13)
0018 236 <RLS,,M>,- :RECORD LENGTH SHORT(B14)
0018 237 <TMK,,M>,- :TAPE MARK DETECTED(B15)
0018 238 >
0018 239 $DEF MS_XSR1 .BLKW 1 :EXTENDED STATUS REGISTER 1
001A 240 _VIELD MS_XSR1,0,<-
001A 241 <MTE,,M>,- :
001A 242 : (PE) MULTI-TRACK ERROR
001A 243 <UNC,,M>,- : (NRZ) VERTICAL PARITY ERROR
001A 244 : (PE) UNCORRECTABLE DATA ERROR(B1)
001A 245 <POL,,M>,- : (NRZ) CYCLIC REDUNDANCY CHECK ERROR
001A 246 : (PE) POSTAMBLE LONG(B2)
001A 247 <POS,,M>,- : (NRZ) LONGITUDINAL REDUNDANCY CHECK ERROR
001A 248 : (PE) POSTAMBLE SHORT(B3)
001A 249 <IED,,M>,- : (NRZ) NOISE RECORD
001A 250 : (PE) INVALID END DATA(B4)
001A 251 <IPO,,M>,- : (NRZ) LRC WAS 0.
001A 252 <SYN,,M>,- : (PE) INVALID POSTAMBLE(B5)
001A 253 : (NRZ) ILLEGAL TAPE MARK
001A 254 <IPR,,M>,- : (PE) SYNCH ERROR(B6)
001A 255 : (NRZ) FRAME DROPOUT
001A 256 <,1>,- : (PE) INVALID PREAMBLE(B7)
001A 257 <SCK,,M>,- : RESERVED BIT
001A 258 <DBF,,M>,- : SPEED CHECK(B9)
001A 259 : (PE) DESKEW BUFFER FAIL(B10)
001A 260 <TIG,,M>,- : (NRZ) NRZ BOARD FIFO OVERFLOW
001A 261 <CRS,,M>,- : TRASH IN GAP(B11)
001A 262 <COR,,M>,- : CREASE DETECTED(B12)
001A 263 <,1>,- : CORRECTABLE DATA(B13)
001A 264 <DLT,,M>,- : UNUSED BIT(B14)
001A 265 : DATA LATE(B15)
001A 266 $DEF MS_XSR2 .BLKW 1 :EXTENDED STATUS REGISTER 2
001C 267 _VIELD MS_XSR2,0,<-
001C 268 <DTP,8>,- :
001C 269 <XSK,,M>,- : DEAD TRACK PARITY,B7-B0
001C 270 <WCF,,M>,- : EXCESSIVE SKEW(B9)
001C 271 <,1>,- : WRITE CLOCK FAIL(B10),BROKEN HARDWARE
001C 272 <CAF,,M>,- : B11 NOT USED
001C 273 <BPE,,M>,- : CAPSTAN ACCELERATION FAIL(B12)
001C 274 <SIP,,M>,- : SERIAL BUS PARITY ERROR AT DRIVE(B13)
001C 275 <OPM,,M>,- : SILO PARITY ERROR(B14)
001C 276 : OPERATION IN PROGRESS(B15)
001C 277 $DEF MS_XSR3 .BLKW 1 :EXTENDED STATUS REGISTER 3
001E 278 _VIELD MS_XSR3,0,<-
001E 279 <RTB,,M>,- :
001E 280 <LXS,,M>,- : REVERSE INTO BOT(B0)
001E 281 <NOI,,M>,- : LIMIT EXCEEDED STATICALLY(B1)
001E 282 <DCK,,M>,- : NOISE RECORD(B2)
001E 283 <CRF,,M>,- : DENSITY CHECK(B3)
001E 284 <REV,,M>,- : CAPSTAN RESPONSE FAIL(B4)
001E 285 <OPI,,M>,- : TAPE MOVED BACKWARDS(B5)
: OPERATION IN COMPLETE(B6)
```



```
001E 286 <LMX,M>,- ;TAPE LIMIT EXCEEDED(B7)
001E 287 <FEC,8>,- ;B15-B8, FATAL ERROR CODE(U-DIAGNOSTIC)
001E 288 >
001E 289
001E 290 $DEFEND MS
0000 291
6CE9300B 0000 292 MEDIA_ID_TS11 = ^X<6CE9300B>
0000 293
0000 294 ; TS11/TS04 TSSR TERMINATION CLASS CODES
0000 295
0000 296
00000000 0000 297 TCC_NML=0 ;NORAML TERMINATION
00000001 0000 298 TCC_ATN=1 ;ATTENTION CONDITION
00000002 0000 299 TCC_TSA=2 ;TAPE STATUS ALERT
00000003 0000 300 TCC_FNR=3 ;FUNCTION REJECT
00000004 0000 301 TCC_REM=4 ;RECOVERABLE ERROR(TAPE MOVED)
00000005 0000 302 TCC_REN=5 ;RECOVERABLE ERROR(TAPE NOT MOVED)
00000006 0000 303 TCC_UER=6 ;UNRECOVERABLE ERROR(TAPE POSI. LOST)
00000007 0000 304 TCC_FTL=7 ;FATAL CONTROLLER ERROR
0000 305
0000 306
0000 307 ; FATAL CLASS (FC) CODES IN TSSR
0000 308
0000 309
00000000 0000 310 FCC_IDF=0 ;INTERNAL DIAG. FAILURE
00000001 0000 311 FCC_CPE=1 ;IO SEQUENCE CROM PARITY ERROR
00000002 0000 312 FCC_UPE=2 ;U-PROCESSOR CROM PARITY ERROR OR OTHER
00000003 0000 313 FCC_LAP=3 ;LOSS OF AC POWER DETECTED
0000 314
0000 315
0000 316 ; TS11/TS04 MESSAGE CODES IN MS_MHD_COD
0000 317
0000 318
00000010 0000 319 MSG_END=^0020 ;END
00000011 0000 320 MSG_FAL=^0021 ;FAIL
00000012 0000 321 MSG_ERR=^0022 ;ERROR
00000013 0000 322 MSG_ATN=^0023 ;ATTENTION
00000014 0000 323 MSG_LOG=^0024 ;LOG (NOT USED)
0000 324
0000 325
0000 326 ; CLASS CODE FOR MESSAGE CODES (MS_MHD_CLS VALUES)
0000 327
0000 328
0000 329 ;**WHEN MSG TYPE=ATTENTION**
00000000 0000 330 CLS_ONF=0 ;ON OR OFFLINE
00000001 0000 331 CLS_MDF=1 ;MICRO DIAG. FAILURE
0000 332 ;**WHEN MSG TYPE=FAIL**
00000000 0000 333 CLS_PTB=0 ;PACKET BAD(SERIAL BUS PARITY ERROR)
00000001 0000 334 CLS_OTHER=1 ;OTHERS
00000002 0000 335 CLS_WLN=2 ;WRITE LOCK ERROR OR NON-EXECUTABLE FUNCTION
00000003 0000 336 CLS_MDE=3 ;MICRO DIAGNOSTIC ERROR
0000 337
0000 338
0000 339 ; TS11/TS04 HARDWARE COMMAND MODES/CODES
0000 340
0000 341
0000 342 ; INTERRUPT ENABLE & ACKNOWLEDGE
```



```
00000000 0000 343 HC_NOP=0 ;SIMULATED NOP (REAL NO OPERATION)
00000000 0000 344 HC_PAK=HC_NOP ;SIMULATED PACK ACKNOWLEDGE
00000000 0000 345 HC_WCK=HC_NOP ;SIMULATED WRITE CHECK
00000000 0000 346 HC_WKR=HC_NOP ;SIMULATED WRITE CHECK REVERSE
00000000 0000 347 HC_RPS=HC_NOP ;SIMULATED READ IN PRESET
00000000 0000 348 HC_SCH=HC_NOP ;SIMULATED SET CHARACTERISTICS
0000 349
0000 350
0000C081 0000 351 HC_RDN=^00001!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;* READ NEXT (FORWARD)
0000C181 0000 352 HC_RDP=^00401!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;* READ PREVIOUS (REVERSE)
0000C281 0000 353 HC_RRP=^01001!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;* REREAD PREVIOUS (SPACE RE
0000C381 0000 354 HC_RRN=^01401!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;* REREAD NEXT (SPACE FWD, R
0000C084 0000 355 HC_WRC=^00004!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;+ WRITE CHARACTERISTICS
0000C085 0000 356 HC_WRD=^00005!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;* WRITE DAT
0000C285 0000 357 HC_WDR=^01005!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;* WRITE DATA RETRY (SPACE R
0000 358 ; WRITE DATA)
0000C086 0000 359 HC_WSM=^00006!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;* WRITE SUBSYSTEM MEMORY
0000C088 0000 360 HC_SRF=^00010!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;$ SPACE RECORDS FORWARD
0000C188 0000 361 HC_SRR=^00410!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;$ SPACE RECORDS REVERSE
0000 362 ;HC_STF=^01010!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;$ SKIP TAPE MARKS FORWARD
0000 363 ;HC_STR=^01410!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;$ SKIP TAPE MARKS REVERSE
0000 364 ;**NOTE** SKIP TAPE MARK COMMANDS ARE SIMULATED BY SKIP RECORD COMMANDS**
0000C088 0000 365 HC_STF=^00010!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;$ SPACE TAPE MARK FORWARD
0000C188 0000 366 HC_STR=^00410!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;$ SPACE TAPE MARKS REVERSE
0000C488 0000 367 HC_RWD=^02010!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;$ REWIND
0000C089 0000 368 HC_WTM=^00011!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- WRITE TAPE MARK
0000C189 0000 369 HC_ERS=^00411!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- ERASE
0000C289 0000 370 HC_WTR=^01011!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- WRITE TAPE MARK RETRY (SP
0000 371 ; ERASE, WRITE TAPE MARK)
0000C08A 0000 372 HC_BRL=^00012!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- MESSAGE BUFFER RELEASE
0000C18A 0000 373 HC_UNL=^00412!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- REWIND AND UNLOAD
0000C28A 0000 374 HC_CLN=^01012!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- CLEAN
0000C08B 0000 375 HC_DRI=^00013!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- DRIVER INITIALIZE
0000C08F 0000 376 HC_GST=^00017!MS_CPHD_M_IE!MS_CPHD_M_CVC!MS_CPHD_M_ACK ;- GET STATUS IMMEDIATE
0000 377 ;**NOTE**
0000 378 ; * => DATA XFR
0000 379 ; + => (SPECIAL)
0000 380 ; $ => POSITION
0000 381 ; - => FORMAT, CONTROL, INITIALIZE, & STATUS
0000 382
0000 383
0000 384 ; DEFINE DEVICE DEPENDENT UNIT CONTROL BLOCK OFFSETS
0000 385 ;
0000 386
0000 387 $DEFINI UCB
0000 388
0000 389 $VIELD UCB,0,<- ;DEV. DEP. STATUS BITS IN UCBSW_DEVSTS
0000 390 <MS_FEF,,M>,- ;TAPE IS PAST ONE TAPE MARK
0000 391 <MS_SWAP,,M>,- ;*SWAP BYTES FOR COMPATIBILITY MODE
0000 392 <MS_IWR,,M>,- ;*INHIBIT WRITE RETRIES
0000 393 <MS_SER,,M>,- ;SELECT ERROR HAS OCCURRED????
0000 394 <MS_RWD,,M>,- ;UNIT IS REWINDING
0000 395 <MS_RDPR,,M>,- ;REQUEST DATAPATH FLAG
0000 396 <MS_SWE,,M>,- ;DOING SOFTWARE EMULATION
0000 397 <MS_NER,,M>,- ;NO ERROR RECOVERY
0000 398 <MS_UMD,,M>,- ;USER MODE DIAGNOSTIC REQUEST
0000 399 <MS_RSP,,M>,- ;REWIND/SPACE IN PROGRESS
```



```
0000 400 <MS_LBA,,M>,- ;LOADING BUFFER ADDR. INTO TS04
0000 401 <MS_RPI,,M>,- ;RPOSITIONING IN PROGRESS
0000 402 <MS_VCK,,M>,- ;VOLUME CHECK
0000 403 <MS_RIP,,M>,- ;RETRY IN PROGRESS FLAG
0000 404 >
0000 405
0000 406
0000 407 ;** STATUS BITS DEFINED ELSEWHERE**
0000 408 ;** IN UCBSL_DEVDEPEND:
0000 409 ;** MTSM_PARITY=1, IF EVEN;0, IF ODD
0000 410 ;** MTSV_FORMAT=MTSK_DEFAULT/NORMAL11/CORDMP11/NORMAL15
0000 411 ;** MTSV_DENSITY=MTSK_PE_1600/MTSK_NRZI-800
0000 412 ;** MTSM_BOT=TAPE IS AT BOT
0000 413 ;** MTSM_EOF=TAPE AT EOF
0000 414 ;** MTSM_EOT=TAPE AT EOT
0000 415 ;** MTSM_HWL=HARDWARE WRITE LOCKED
0000 416 ;** MTSM_LOST=TAPE POSITION LOST
0000 417 ;** IN UCBSW_STS:
0000 418 ;** UCBSM_TIM=TIMEOUT ENABLED
0000 419 ;** UCBSM_INT=INTERRUPT EXPECTED
0000 420 ;** UCBSM_ERLOGIP=ERRORLOG IN PROGRESS
0000 421 ;** UCBSM_CANCEL=CANCEL I/O
0000 422 ;** UCBSM_ONLINE=UNIT ONLINE
0000 423 ;** UCBSM_POWER=POWER FAILED WHILE UNIT BUSY
0000 424 ;** UCBSM_TIMEOUT=UNIT TIME OUT
0000 425 ;** UCBSM_INTTYPE=RECEIVER INTERRUPT,IF SET
0000 426 ;** UCBSM_BSY=UNIT IS BUSY
0000 427 ;** UCBSM_MOUNTING=DEVICE IS BEING MOUNTED
0000 428 ;** UCBSM_DEADMO=DEALLOCATE AT DISMOUNT
0000 429 ;** UCBSM_VALID=VOLUME IS SOFTWARE VALID
0000 430 ;** UCBSM_UNLOAD=UNLOAD VOLUME AT DISMOUNT
0000 431 ;** IN UCBSL_DEVCHAR:
0000 432 ;** .....
0000 433 ;** DEVS_M_SWL=SOFTWARE WRITE LOCKED
0000 434 ;** .....
0000 435 ; NEW EXTENSION TO UCB FOR TS11/TS04
0000 436 ;
0000 437
000000B4 0000 438 .=UCBSK_LCL_TAPE_LENGTH
00B4 439 $DEF UCBSW_MS_SPACNT .BLKW 1 ;SPACING COUNT
00B6 440 $DEF UCBSL_MS_TSPT1 .BLKL 1 ;PTR. TO TS04 BUFFER IN
00BA 441 ;NON-PAGED POOL
00BA 442 $DEF UCBSL_MS_TSPT2 .BLKL 1 ;CORRESPONDING UNIBUS ADDR.
00BE 443 $DEF UCBSW_MS_TSPT3 .BLKW 1 ;COMMAND PTR FOR TS11/TS04
00C0 444 $DEF UCBSW_MS_TSBA .BLKW 1 ;TS11/TS04 DEVICE REGISTER(TSBA)
00C2 445 $DEF UCBSW_MS_TSSR .BLKW 1 ;TS11/TS04 DEVICE REGISTER(TSSR)
00C4 446 _VIELD MS_TSSR,1,<- ;TS11/TS04 STATUS REGISTER(B0 UNUSED)
00C4 447 <TCC,3>,- ;TERMINATION CLASS CODE FIELD
00C4 448 <FC,2>,- ;FATAL ERROR CLASS CODE FIELD
00C4 449 <OFL,,M>,- ;DEVICE IS OFF-LINE(B6)
00C4 450 <SSR,,M>,- ;SUBSYSTEM READY(B7)
00C4 451 <A16,,M>,- ;BUFFER ADDRESS BIT 16
00C4 452 <A17,,M>,- ;BUFFER ADDRESS BIT 17
00C4 453 <NBA,,M>,- ;NEED BUFFER ADDRESS(B10)
00C4 454 <NXM,,M>,- ;NON-EXISTENT MEMORY(B11)
00C4 455 <RMR,,M>,- ;REGISTER MODIFICATION REFUSED(B12)
00C4 456 <SPE,,M>,- ;SERIAL BUS PARITY ERROR(B13)
```



```
00C4 457 <UPE,,M>,- ;UNIBUS PARITY ERROR(B14)
00C4 458 <SC,,M>,- ;SPECIAL CONDITION(B15)
00C4 459 >
00C4 460 ;**FATAL ERROR CONDITION: UPE!SPE!NXM!NBA
00C4 461 $DEF UCBSW_MS_XC .BLKW 1 ;BYTES XFERRED OR RECORDS/FILES SKIPPED
00C6 462 $DEF UCBSB_MS_DPN .BLKB 1 ;DATA PATH NUMBER
00C7 463 $DEF UCBSB_MS_PER .BLKB 1 ;PURGE ERROR IF BIT 0 SET
00C8 464 $DEF UCBSL_MS_DPR .BLKL 1 ;DATA PATH REGISTER USED
00CC 465 $DEF UCBSL_MS_FMPR .BLKL 1 ;FINAL MAP REGISTER
00D0 466 $DEF UCBSL_MS_PMPR .BLKL 1 ;FINAL-1(PREVIOUS) MAP REGISTER
00D4 467 ;**NOTE**LAST 1 LONGWORD IS USED DURING
00D4 468 ;****POWERFAIL REPOSITIONING
00D4 469 $DEF UCBSL_MS_NMPR .BLKL 1 ;FINAL+1(NEXT) MAP REGISTER
00D8 470 $DEF UCBSL_MS_OMP .BLKL 1 ;COPY OF VEC$W_MAPREG(LONGWORD IN CRB)
00DC 471 $DEF UCBSL_MS_TIMEOUT .BLKL 1 ;Timeout value for function in progress
00E0 472 $DEF UCBSQ_MS_TMP1 .BLKQ 1 ;TEMP FOR UCBSW_BCNT,BOFF, and SVAPTE
00E8 473 $DEF UCBSL_MS_TMP2 .BLKL 1 ;TEMP. FOR CRB$C_INTD+VEC$W_MAPREG
00EC 474 $DEF UCBSQ_MS_BUF SVAPTE ;AREA TO SAVE PARAMETERS TO MAP MESSAGE
000000F4 00EC 475 .BLKQ 1 ; BUFFER IN UNIBUS SPACE
00F4 476 $DEF UCBSL_MS_TPOSITN .BLKL 1 ;TAPE POSITION AT POWERFAIL
00F8 477 $DEF UCBSW_MS_MHD .BLKW 1 ;MESSAGE PACKET**COPY IN ICB**
00FA 478 $DEF UCBSW_MS_LNH .BLKW 1 ;MESSAGE LENGTH WORD
00FC 479 $DEF UCBSW_MS_RBPC .BLKW 1 ;RESIDUAL BYTE/POSITOIN COUNT
00FE 480 $DEF UCBSW_MS_XSR0 .BLKW 1 ;EXTENDED STATUS REGISTER 0
0100 481 $DEF UCBSW_MS_XSR1 .BLKW 1 ;EXTENDED STATUS REGISTER 1
0102 482 $DEF UCBSW_MS_XSR2 .BLKW 1 ;EXTENDED STATUS REGISTER 2
0104 483 $DEF UCBSW_MS_XSR3 .BLKW 1 ;EXTENDED STATUS REGISTER 3
0106 484
0106 485 .IF DF TS_TRACE
0106 486
0106 487 $DEF UCBSW_TRACESTS .BLKW 1 ; Status of trace.
0106 488 $DEF UCBSL_TRACEBEG .BLKL 1 ; Pointer to beginning of trace ring.
0106 489 $DEF UCBSL_TRACEPTR .BLKL 1 ; Pointer to next available slot.
0106 490 $DEF UCBSL_TRACEND .BLKL 1 ; Pointer to beyond trace ring.
0106 491
0106 492 TRACE_V_ACTIVE=0
0106 493 TRACE_M_ACTIVE=1
0106 494
0106 495 .ENDC
00000106 0106 496 UCBSK_MS_LENGTH=.
0106 497 $DEFEND UCB
```



```
0000 499 .SBTTL DRIVER TABLES
0000 500
0000 501 :
0000 502 : DRIVER PROLOGUE TABLE
0000 503 :
0000 504
0000 505 DPTAB - ;DEFINE DRIVER PROLOGUE TABLE
0000 506 END=TS END,- ;END OF DRIVER
0000 507 ADAPTER=UBA,- ;UNIBUS ADAPTER
0000 508 UCBSIZE=UCB$K_MS_LENGTH,-
0000 509 NAME=TSDRIVER ;DRIVER NAME
0038 510 DPT_STORE INIT ;CONTROL BLOCK INIT VALUE
0038 511 DPT_STORE DDB,DDBSL_ACPD,L,<^A\MTA\> ;DEFAULT ACP NAME
003F 512 DPT_STORE UCB,UCBSB_FIPL,B,8 ;FORK IPL
0043 513 DPT_STORE UCB,UCBSL_DEVCHAR,L,- ;DEVICE CHARACTERISTICS
0043 514 <DEVSM_FOD- ;FILES ORIENTED
0043 515 !DEVSM_DIR- ;DIRECTORY STRUCTURED
0043 516 !DEVSM_AVL- ;AVAILABLE
0043 517 !DEVSM_ELG- ;ERROR LOGGING ENABLED
0043 518 !DEVSM_IDV- ;INPUT DEVICE
0043 519 !DEVSM_ODV- ;OUTPUT DEVICE
0043 520 !DEVSM_SDI- ;SINGLE DIRECTORY DEVICE
0043 521 !DEVSM_SQD> ;SEQUENTIAL DEVICE
004A 522 DPT_STORE UCB,UCBSL_DEVCHAR2,L,- ;DEVICE CHARACTERISTICS
004A 523 <DEVSM_NNM> ;PREFIX NAME WITH 'node$'
0051 524 DPT_STORE UCB,UCBSB_DEVCLASS,B,DC$ TAPE ;DEVICE CLASS
0055 525 DPT_STORE UCB,UCBSB_DEVTYP, B,DT$ TS11 ;DEVICE TYPE
0059 526 DPT_STORE UCB,UCBSL_MEDIA_ID,L,MEDIA_ID TS11 ;DEVICE MEDIA ID
0060 527 DPT_STORE UCB,UCBSW_DEVBUFSIZ,W,2048- ;DEFAULT BUFFER SIZE
0065 528 DPT_STORE UCB,UCBSL_DEVDEPEND,W,<^X4C0> ;DEFAULT TAPE PARAMETERS
006A 529 ;FORMAT=NORMAL11,DENSITY=1600BPI
006A 530 DPT_STORE UCB,UCBSB_DIPL,B,21 ;DEVICE IPL
006E 531 DPT_STORE UCB,UCBSB_ERTCNT,B,16 ;ERROR RETRY COUNT
0072 532 DPT_STORE UCB,UCBSB_ERTMAX,B,16 ;MAX ERROR RETRY COUNT
0076 533 DPT_STORE REINIT ;CONTROL BLOCK RE-INIT VALUES
0076 534 DPT_STORE CRB,CRBSL_INTD+4,D,TS$INT ;INTERRUPT SERVICE ROUTINE ADDR.
007B 535 DPT_STORE CRB,CRBSL_INTD+VEC$L UNITINIT,D,TS INIT ;UNIT INIT
0080 536 DPT_STORE DDB,DDBSL_DDT,D,MS$DDT ;DDT ADDRESS
0085 537 DPT_STORE END ;
00000001 0000 538 .MDELETE DPT_STORE
0000 539
0000 540 :
0000 541 : DRIVER DISPATCH TABLE
0000 542 :
0000 543
0000 544 DDTAB MS,- ;(MS=GENERIC NAME)DRIVER DISPATCH TABLE
0000 545 TS_STARTIO,- ;START I/O OPERATION
0000 546 0,- ;UNSOLICITED INTERRUPT
0000 547 TS_FUNCABLE,- ;FUNCTION DECISION TABLE
0000 548 +IOC$CANCELIO,- ;CANCEL I/O ENTRY POINT(STANDARD)
0000 549 TS_REGDUMP,- ;REGISTER DUMP ROUTINE
0000 550 <8+4+<1+23>*4>,- ;DIAG. BUFFER SIZE
0000 551 <<1+23>*4+EMBSL_DV_REGSAV> ;ERROR BUFFER SIZE
0038 552
0038 553 :
0038 554 : HARDWARE COMMAND TABLE - MODES/CODES
0038 555 :
```


0038	556			
0038	557	HCTAB:		
0038	558	GENHC	HC_NOP	:SIMULATED NOP
003A	559	GENHC	HC_UNL	:REWIND & UNLOAD
003C	560	GENHC	HC_STF	:SKIP TAPE MARK FORWARD(SPACE FILE)
003E	561	GENHC	HC_RWD	:REWIND
0040	562	GENHC	HC_DRI	:DRIVE INITIALIZE(DRIVE CLEAR)
0042	563	GENHC	HC_STR	:SKIP TAPE MARK REVERSE
0044	564	GENHC	HC_ERS	:ERASE
0046	565	GENHC	HC_SRR	:SKIP RECORD REVERSE
0048	566	GENHC	HC_PAK	:SIMULATED PACK ACKNOWLEDGE
004A	567	GENHC	HC_SRF	:SKIP RECORD FORWARD
004C	568	GENHC	HC_WCK	:SIMULATED WRITECHECK
004E	569	GENHC	HC_WRD	:WRITE DATA(WRITEPBLK)
0050	570	GENHC	HC_RDN	:READ DATA NEXT(READPBLK)
0052	571	GENHC	HC_WKR	:SIMULATED WRITECHECK REV.
0054	572	GENHC	HC_WRD	:WRITE DATA(NO WRITEPBLK REV.)
0056	573	GENHC	HC_RDP	:READ DATA PREVIOUS
0058	574	GENHC	HC_RRN	:REREAD DATA NEXT
005A	575	GENHC	HC_RRP	:REREAD DATA PREVIOUS
005C	576	GENHC	HC_WDR	:WRITE DATA RETRY
005E	577	GENHC	HC_RPS	:SIMULATED READ PRESET
0060	578	GENHC	HC_SCH	:SIMULATED SET CHARACTERISTIC
0062	579	GENHC	HC_GST	:GET STATUS IMMEDIATE
0064	580	GENHC	HC_WTM	:WRITE TAPE MARK
0066	581	GENHC	HC_WTR	:WRITE TAPE MARK RETRY
0068	582	GENHC	HC_CLN	:CLEAN
006A	583	GENHC	HC_BRL	:MESSAGE BUFFER RELEASE
006C	584	GENHC	HC_WSM	:WRITE SUBSYSTEM MEMORY
006E	585	GENHC	HC_WRC	:WRITE CHARACTERISTIC
0070	586			
0070	587			


```
0070 589 ;+
0070 590
0070 591 : TS11/TS04 FUNCTION DECISION TABLE
0070 592 :-
0070 593
0070 594 TS_FUNCTABLE:
0070 595 FUNCTAB
0070 596 <NOP,-
0070 597 UNLOAD,-
0070 598 SPACERECORD,-
0070 599 RECAL,-
0070 600 DRVCLR,-
0070 601 READPRESET,-
0070 602 PACKACK,-
0070 603 ERASETAPE,-
0070 604 SENSECHAR,-
0070 605 SETCHAR,-
0070 606 SPACEFILE,-
0070 607 WRITECHECK,-
0070 608 WRITEPBLK,-
0070 609 WRITERET,-
0070 610 READPBLK,-
0070 611 REREADN,-
0070 612 REREADP,-
0070 613 AVAILABLE,-
0070 614 WRITEMARK,-
0070 615 WRTTMKR,-
0070 616 CLEAN,-
0070 617 READLBLK,-
0070 618 WRITELBLK,-
0070 619 SENSEMODE,-
0070 620 SETMODE,-
0070 621 REWIND,-
0070 622 REWINDOFF,-
0070 623 SKIPRECORD,-
0070 624 SKIPFILE,-
0070 625 WRITEOF,-
0070 626 READVBLK,-
0070 627 WRITEVBLK,-
0070 628 ACCESS,-
0070 629 ACPCONTROL,-
0070 630 CREATE,-
0070 631 DEACCESS,-
0070 632 DELETE,-
0070 633 MODIFY,-
0070 634 MOUNT>
0078 635 FUNCTAB,-
0078 636 <NOP,-
0078 637 UNLOAD,-
0078 638 SPACERECORD,-
0078 639 RECAL,-
0078 640 DRVCLR,-
0078 641 READPRESET,-
0078 642 PACKACK,-
0078 643 ERASETAPE,-
0078 644 SENSECHAR,-
0078 645 SETCHAR,-

;FUNCTION DECISION TABLE
;LEGAL FUNCTIONS
;NO OPERATION
;UNLOAD VOLUME
;SPACE RECORDS
;RECALIBRATE (REWIND)
;DRIVER CLEAR
;READ IN PRESET
;PACK ACKNOWLEDGE
;ERASE TAPE
;SENSE TAPE CHARACTERISTICS
;SET CHARACTERISTICS
;SPACE FILE
;WRITE CHECK FORWARD
;WRITE PHYSICAL BLOCK
;**NEW**WRITE PHYSICAL BLOCK RETRY
;READ PHYSICAL BLOCK
;**NEW**REREAD NEXT
;**NEW**REREAD PREVIOUS
;AVAILABLE (REWIND/NOWAIT CLEAR VALID)
;WRITE TAPE MARK
;**NEW**WRITE TAPE MARK RETRY
;**NEW**CLEAN TAPE
;READ LOGICAL BLOCK
;WRITE LOGICAL BLOCK
;SENSE TAPE MODE
;SET MODE
;REWIND
;REWIND AND SET OFFLINE
;SKIP RECORDS
;SKIP FILES
;WRITE END OF FILE
;READ VIRTUAL BLOCK
;WRITE VIRTUAL BLOCK
;ACCESS FILE AND/OR FIND DIRECTORY
;ACP CONNTROL FUNCTION
;CREATE FILE AND/OR CREATE DIRECTORY
;DEACCESS FILE
;DELETE FILE AND/OR DIRECTORY ENTRY
;MODIFY FILE ATTRIBUTES
;MOUNT VOLUME
;BUFFERED I/O FUNCTIONS
;NO OPERATION
;UNLOAD VOLUME
;SPACE RECORDS
;RECALIBRATE (REWIND)
;DRIVE CLEAR
;READ PRESET
;PACK ACKNOWLEDGE
;ERASE TAPE
;SENSE CHARACTERISTICS
;SET CHARACTERISTICS
```


0078	646	SPACEFILE,-	:SPACE FILES
0078	647	WRITEMARK,-	:WRITE TAPE MARK
0078	648	WRTTMKR,-	:**NEW**WRITE TAPE MARK RETRY
0078	649	CLEAN,-	:**NEW**CLEAN TAPE
0078	650	SENSEMODE,-	:SENSE MODE
0078	651	SETMODE,-	:SET MODE
0078	652	REWIND,-	:REWIND
0078	653	REWINDOFF,-	:REWIND AND UNLOAD
0078	654	SKIPRECORD,-	:SKIP RECORDS
0078	655	SKIPFILE,-	:SKIP FILES
0078	656	WRITEOF,-	:WRITE END OF FILE
0078	657	ACCESS,-	:ACCESS FILE AND/OR FIND DIRECTORY ENTRY
0078	658	ACPCONTROL,-	:ACP CONTROL FUNCTION
0078	659	CREATE,-	:CREATE FILE AND/OR CREATE DIRECTORY ENTRY
0078	660	DEACCESS,-	:DEACCESS FILE
0078	661	DELETE,-	:DELETE FILE AND/OR DIRECTORY ENTRY
0078	662	MODIFY,-	:MODIFY FILE ATTRIBUTES
0078	663	MOUNT>	:MOUNT VOLUME
0080	664	FUNCTAB +ACPSREADBLK,-	:READ FUNCTIONS
0080	665	<READLBLK,-	:READ LOGICAL BLOCK FORWARD
0080	666	READPBLK,-	:READ PHYSICAL BLOCK FORWARD
0080	667	REREADN,-	:*NEW*REREAD NEXT
0080	668	REREADP,-	:*NEW*REREAD PREVIOUS
0080	669	READVBLK>	:READ VIRTUAL BLOCK
008C	670	FUNCTAB +ACPSWRITEBLK,-	:WRITE FUNCTIONS
008C	671	<WRITECHECK,-	:WRITE CHECK FORWARD
008C	672	WRITELBLK,-	:WRITE LOGICAL BLOCK
008C	673	WRITEPBLK,-	:WRITE PHYSICAL BLOCK
008C	674	WRITERET,-	:*NEW*WRITE RETRY
008C	675	WRITEVBLK>	:WRITE VIRTUAL BLOCK
0098	676	FUNCTAB +ACPSACCESS,<ACCESS,CREATE>	:ACCESS AND CREATE FILE OR DIRECTORY
00A4	677	FUNCTAB +ACPSDEACCESS,<DEACCESS>	:DEACCESS FILE
00B0	678	FUNCTAB +ACPSMODIFY,-	:
00B0	679	<ACPCONTROL,-	:ACP CONTROL FUNCTION
00B0	680	DELETE,-	:DELETE FILE OR DIRECTORY ENTRY
00B0	681	MODIFY>	:MODIFY FILE ATTRIBUTES
00BC	682	FUNCTAB +ACPSMOUNT,<MOUNT>	:MOUNT VOLUME
00C8	683	FUNCTAB +MTSCHECK ACCESS,-	:MAGTAPE CHECK ACCESS FUNCITONS
00C8	684	<ERASETAPE,-	:ERASE TAPE
00C8	685	CLEAN,-	:**NEW**CLEAN TAPE
00C8	686	WRITEMARK,-	:WRITE TAPE MARK
00C8	687	WRTTMKR,-	:*NEW*WRITE TAPE MARK RETRY
00C8	688	WRITEOF>	:WRITE END OF FILE
00D4	689	FUNCTAB +EXESZEROPARM,-	:ZERO PARAMETER FUNCTIONS
00D4	690	<NOP,-	:NO OPERATION
00D4	691	UNLOAD,-	:UNLOAD VOLUME
00D4	692	RECAL,-	:RECALIBRATE (REWIND)
00D4	693	REWIND,-	:REWIND
00D4	694	REWINDOFF,-	:REWIND AND SET OFFLINE
00D4	695	DRVCLR,-	:DRIVE CLEAR
00D4	696	READPRESET,-	:READ IN PRESET
00D4	697	PACKACK,-	:PACK ACKNOWLEDGE
00D4	698	ERASETAPE,-	:ERASE TAPE
00D4	699	CLEAN,-	:**NEW**CLEAN TAPE
00D4	700	SENSECHAR,-	:SENSE TAPE CHARACTERISTICS
00D4	701	SENSEMODE,-	:SENSE TAPE MODE
00D4	702	AVAILABLE,-	:AVAILABLE (REWIND/NOWAIT CLEAR VALID)

TSDRIVER
V04-000

B 4

- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00 Page 14
DRIVER TABLES 5-SEP-1984 00:18:15 [DRIVER.SRC]TSDRIVER.MAR;1 (1)

00D4	703		WRITEMARK,-	;WRITE TAPE MARK
00D4	704		WRITMKR,-	;*NEW*WRITE TAPE MARK RETRY
00D4	705		WRITEOF>	;WRITE END OF FILE
00E0	706	FUNCTAB	+EXESONEPARM,-	;ONE PARAMETER FUNCTIONS
00E0	707		<SPACERECORD,-	;SPACE RECORDS
00E0	708		SPACEFILE,-	;SPACE FILES
00E0	709		SKIPRECORD,-	;SKIP RECORDS
00E0	710		SKIPFILE>	;SKIP FILES
00EC	711	FUNCTAB	+EXESSETMODE,-	;SET TAPE CHARACTERISTICS
00EC	712		<SETCHAR,-	;
00EC	713		SETMODE>	;
00F8	714			;


```
00F8 716      .IF      DF      TS_TRACE
00F8 717      .SBTTL  +      TRACE_IRP and TRACE_STATUS
00F8 718
00F8 719      ; Routines to record IRP and I/O status contents in the trace table.
00F8 720      ; Trace table entries are 96 bytes long so that they line up nicely in
00F8 721      ; a dump.
00F8 722
00F8 723      ; TRACE_IRP
00F8 724
00F8 725      ; Inputs:
00F8 726      ;      R3 => IRP
00F8 727      ;      R5 => UCB
00F8 728
00F8 729      TRACE_IRP:
00F8 730
00F8 731      BBC      #TRACE_V_ACTIVE,-      ; If trace table not intialized,
00F8 732      UCB$W_TRACESTS(R5),20$      ; branch around.
00F8 733      MOVQ     R0,-(SP)      ; Save R0 and R1.
00F8 734      MOVL     R3,R0      ; R0 => IRP to trace.
00F8 735      CMPL     UCB$L_TRACEEND(R5),-      ; See if we should circle back to start
00F8 736      UCB$L_TRACEPTR(R5)      ; of trace table.
00F8 737      BGTR     10$      ; GTR implies NO.
00F8 738      MOVL     UCB$L_TRACEBEG(R5),-      ; TRACE_PTR => base of trace table.
00F8 739      UCB$L_TRACEPTR(R5)
00F8 740      10$:
00F8 741      MOVL     UCB$L_TRACEPTR(R5),R1      ; R1 => area in trace table to use.
00F8 742
00F8 743      MOVQ     (R0)+,(R1)+      ; Twelve quad words are 96 bytes.
00F8 744      MOVQ     (R0)+,(R1)+
00F8 745      MOVQ     (R0)+,(R1)+
00F8 746      MOVQ     (R0)+,(R1)+
00F8 747      MOVQ     (R0)+,(R1)+
00F8 748      MOVQ     (R0)+,(R1)+
00F8 749      MOVQ     (R0)+,(R1)+
00F8 750      MOVQ     (R0)+,(R1)+
00F8 751      MOVQ     (R0)+,(R1)+
00F8 752      MOVQ     (R0)+,(R1)+
00F8 753      MOVQ     (R0)+,(R1)+
00F8 754      MOVQ     (R0)+,(R1)+
00F8 755
00F8 756      MOVL     UCB$L_TRACEPTR(R5),R1      ; R1 => area in trace table to use.
00F8 757      MOVL     R3,(R1)      ; Trace entry => IRP.
00F8 758      MNEGL     #1,4(R1)      ; Init flag field.
00F8 759      MNEGL     #1,IRP$L_ARB(R1)      ; Init field for I/O Status #1.
00F8 760      MNEGL     #1,IRP$L_ARB+4(R1)      ; Init field for I/O Status #2.
00F8 761      MOVQ     (SP)+,R0      ; Restore R0 and R1.
00F8 762      20$:
00F8 763      RSB
00F8 764
00F8 765      ; TRACE_STATUS
00F8 766
00F8 767      ; Inputs:
00F8 768
00F8 769      ;      R0 = I/O status value #1.
00F8 770      ;      R5 => UCB
00F8 771      ;      UCB$L_DEVDEPEND = I/O status #2.
00F8 772
```



```

00F8 773 TRACE_STATUS:
00F8 774
00F8 775 BBC #TRACE_V_ACTIVE,- ; If Trace table not active, branch.
00F8 776 UCB$W_TRACESTS(R5),30$
00F8 777 PUSHL R2 ; Save register.
00F8 778 MOVL UCB$L_TRACEPTR(R5),R2 ; R2 => area in trace table to use.
00F8 779
00F8 780 MOVL R0,IRP$L_ARB(R2) ; Save I/O status.
00F8 781 MOVL UCB$L_DEVDEPEND(R5),- ;
00F8 782 IRP$L_ARB+4(R2)
00F8 783 POPL R2 ; Restore register.
00F8 784 ADDL #96,UCB$L_TRACEPTR(R5) ; Point to next entry.
00F8 785 30$:
00F8 786 RSB ; Return to caller.
00F8 787
00F8 788 .ENDC
  
```



```
00F8 790 .SBTTL UNIT INITIALIZATION ROUTINE
00F8 791 :+
00F8 792 : THIS ROUTINE IS CALLED WHEN THE DRIVER IS LOADED OR ON POWERFAIL
00F8 793 : RECOVERY.
00F8 794 :
00F8 795 : CALLING SEQUENCE:
00F8 796 :     JSB     TS_INIT
00F8 797 :
00F8 798 : INPUT:
00F8 799 :     R5 = UCB ADDRESS
00F8 800 :     R4 = EQUIVALENT CSR FOR TS11
00F8 801 :
00F8 802 : OUTPUT:
00F8 803 :
00F8 804 :
00F8 805 TS_INIT:
10  A8 00F8 806 BISW #UCBSM_ONLINE,- ; Always mark TS11 as online since
64 A5 00FA 807 UCBSW_STS(R5) ; interrupts are not normally enabled
00FC 808 ; we have no method to set it on
05 11 00FC 809 ; dynamically.
00FE 810 BRB 50$ ; Go to allocate buffer and load registers
10  AA 00FE 811 15$: BICW #UCBSM_ONLINE,- ; Only reason for marking TS11 offline
64 A5 0100 812 UCBSW_STS(R5) ; is lack of pool space for PACKET.
0102 813 20$:
05 0102 814 RSB ;RETURN
0103 815 50$:
0103 816 .IF DF TS_TRACE
0103 817 BBS #TRACE_V_ACTIVE,- ; If trace table already intialized,
0103 818 UCBSW_TRACESTS(R5),52$ ; branch around.
0103 819 MOVL #50*96+16,R1 ; Allocate trace table for 50 entries.
0103 820 PUSHL G^EXESGL_NONPAGED ; Save nonpaged IPL.
0103 821 MFPR #PRS_IPL,G^EXESGL_NONPAGED ; Use current IPL.
0103 822 JSB G^EXESALONONPAGED ; Get from non-paged memory.
0103 823 POPL G^EXESGL_NONPAGED ; Restore nonpaged IPL.
0103 824 BLBC R0,52$ ; Space not available, branch around.
0103 825
0103 826 CLRQ (R2)+ ; Initialize trace table header for SDA.
0103 827 MOVW R1,(R2)+ ; Save size.
0103 828 MOVW #DYN$C_SCS,(R2)+ ; Type.
0103 829 CLRL (R2)+ ; Round header upto 16 byte boundary.
0103 830 MOVL R2,UCBSL_TRACEBEG(R5) ; Save pointer to base of trace tabl
0103 831 MOVL R2,UCBSL_TRACEPTR(R5) ; Pointer to next area to use.
0103 832 ADDL3 #50*96,R2,- ; Pointer to beyond end of trace
0103 833 UCBSL_TRACEEND(R5) ; table.
0103 834 BISW #TRACE_M_ACTIVE,- ; Indicate Trace table initied.
0103 835 UCBSW_TRACESTS(R5)
0103 836
0103 837 52$:
0103 838 .ENDC
51 24 A5 DO 0103 839 MOVL UCBSL_CRB(R5),R1 ;GET POINTER TO CRB
34 A1 DO 0107 840 MOVL CRBSL_INTD+VECSW_MAPREG(R1),-
00E8 C5 DO 010A 841 UCBSL_MS_TMP2(R5) ;SAVE CURRENT UBA MAP CONTEXT.
50 2C A1 DO 010D 842 MOVL CRBSL_INTD+VECSL_IDB(R1),R0 ;GET POINTER TO IDB
04 A0 55 DO 0111 843 MOVL R5,IDBSL_OWNER(R0) ;MAKE UCB OWNER OF IDB
51 20 DO 0115 844 MOVL #32,R1 ;SIZE OF WORK BUFFER FOR TS11(=32.)
52 00B6 C5 DO 0118 845 MOVL UCBSL_MS_TSPT1(R5),R2 ;IF THE BUFFER HAS ALREADY BEEN ALLOCATED
25 12 011D 846 BNEQ 60$ ;BRANCH AROUND ELSE ALLOCATE THE BUFFER
```



```
011F 847
011F 848 : DRIVER LOAD
011F 849 :
011F 850 :
011F 851 :
011F 852 55$:
011F 853 PUSHL G^EXESGL_NONPAGED :SAVE NONPAGED IPL
00000000'GF DD 011F 854 MFPR #PR$ IPL,G^EXESGL_NONPAGED :USE CURRENT IPL
00000000'GF 12 DB 0125 854 JSB G^EXESGL_NONPAGED :GET FROM NON-PAGED MEMORY
00000000'GF 16 012C 855 POPL G^EXESGL_NONPAGED :RESTORE NONPAGED IPL
00000000'GF 8ED0 0132 856 BLBS R0,57$ : Space available, branch aroundd.
03 50 E8 0139 857 BRW 15$ : Branch on allocation failure.
FFBF 31 013C 858
013F 859 57$:
013F 860 :YES, R1=SIZE OF ALLOCATED BLOCK
013F 861 : R2 HAS ADDR. OF THE BLOCK
00B6 C5 52 D0 013F 862 MOVL R2,UCB$L_MS_TSPT1(R5) :STORE ADDR. IN UCB
0144 863 60$:
0144 864 ASSUME UCB$W_BOFF EQ UCB$L_SVAPTE+4
0144 865 ASSUME UCB$W_BCNT EQ UCB$W_BOFF+2
78 A5 7D 0144 866 MOVQ UCB$L_SVAPTE(R5),-
00E0 C5 0147 867 UCB$Q_MS_TMP1(R5) :SAVE UCB$L_SVAPTE, W_BCNT, W_BOFF.
014A 868
7E A5 51 B0 014A 869 MOVW R1,UCB$W_BCNT(R5) :LOAD BYTE COUNT INTO UCB
7C A5 52 FE00 8F AB 014E 870 BICW3 #^XFE00,R2,UCB$W_BOFF(R5) :LOAD BYTE OFFSET IN UCB
52 52 15 09 EF 0155 871 EXTZV S^#VASV_VPN,S^#VASS_VPN,R2,R2 :GET VIRTUAL PAGE #
50 00000000'GF D0 015A 872 MOVL G^MMG$G[SPTBASE,R0] :GET ADDR. OF SYS. PAGE TABLE
78 A5 6042 DE 0161 873 MOVAL (R0)[R2],UCB$L_SVAPTE(R5) :STORE SVA OF PTE FOR WORK BUFFER
0166 874 :LOADED BCNT,BOFF,&SVAPTE FOR WORK BUFFER
0166 875 :DIRECT DATA PATH IS USED FOR COMMUNICATION
51 24 A5 D0 0166 876 MOVL UCB$L_CRB(R5),R1 : R1 => CRB
34 A1 00D8 C5 D0 016A 877 MOVL UCB$L_MS_OMPR(R5),CRB$L_INTD+VECSW_MAPREG(R1) :IF NEQ USE OLD MAP RE
13 12 0170 878 BNEQ 80$ :GOTO LOAD MAP REGISTER
37 A1 94 0172 879 70$:
0172 880 CLRB CRB$L_INTD+VECSB_DATAPATH(R1) :INSURE DIRECT DATA PATH(=0)
0175 881 REQMPR :ALLOCATE MAP REGISTER(S) TO MAP UNIBUS
51 24 A5 D0 017B 882 MOVL UCB$L_CRB(R5),R1 :GET POINTER TO CRB
00D8 C5 34 A1 D0 017F 883 MOVL CRB$L_INTD+VECSW_MAPREG(R1),UCB$L_MS_OMPR(R5) :SAVE OLD MAP REGISTER
0185 884 80$:
78 A5 7D 0185 885 MOVQ UCB$L_SVAPTE(R5),- : Save message buffer parameters to
00EC C5 0188 886 UCB$Q_MS_BUF$SVAPTE(R5) : facilitate later remapping.
018B 887 :TO SBI ADDRESSES
018B 888 : THE NO. OF MAP REGISTER AND STARTING
018B 889 : MAP REG. NO. ARE STORED IN CRB
018B 890 :LOAD MAP REG. TO BE USED
LOADUBA
0191 891 :
0191 892 : CALCULATE UNIBUS ADDR. FOR COMMAND PACKET, STORE IT IN UCB
0191 893 :
50 7C A5 3C 0191 894 MOVZWL UCB$W_BOFF(R5),R0 :GET BYTE OFFSET
00EC C5 7D 0195 895 MOVQ UCB$Q_MS_TMP1(R5),-
78 A5 0199 896 UCB$L_SVAPTE(R5) :RESTORE SVAPTE, BOFF, BCNT
019B 897
51 24 A5 D0 019B 898 MOVL UCB$L_CRB(R5),R1 :GET CRB
50 09 09 34 A1 F0 019F 899 INSV CRB$L_INTD+VECSW_MAPREG(R1),#9,#9,R0 : HGH 9 BITS
00BA C5 50 D0 01A5 900 MOVL R0,UCB$L_MS_TSPT2(R5) :STORE IN UCB
00E8 C5 D0 01AA 901 MOVL UCB$L_MS_TMP2(R5),-
34 A1 01AE 902 CRB$L_INTD+VECSW_MAPREG(R1) :RESTORE UNIBUS MAPPING CONTEXT
51 D4 01B0 903 CLRL R1 :CLEAR R1
```



```

50 50 FE 8F 78 01B2 904 ASHL # -2, R0, R0 ;MODULO 4, SHIFT OUT 2 0'S
51 0E 02 50 F0 01B7 905 INSV R0, #2, #14, R1 ;INSERT B2-B15
50 50 F2 8F 78 01BC 906 ASHL # -14, R0, R0 ;SHIFT OUT B2-B15
51 02 00 50 F0 01C1 907 INSV R0, #0, #2, R1 ;INSERT B16-B17
00BE C5 51 B0 01C6 908 MOVW R1, UCBSW_MS_TSPT3(R5) ;STORE COMMAND PTR IN UCB
01CB 909
01CB 910
01CB 911
01CB 912
50 00B6 C5 D0 01CB 913 MOVW UCBSL_MS_TSPT1(R5), R0 ;COMMAND PACKET ADDR. IN R0
60 C0B4 8F B0 01D0 914 MOVW #<HC WRC?MS CPHD M_ACK>, MS_CPHD(R0) ;GET COMMAND PACKET HEADER
02 A0 00BA C5 D0 01D5 915 MOVW UCBSL_MS_TSPT2(R5), MS_BACT(R0) ;STORE CHAR. BUFFER ADDR.
02 A0 08 C0 01DB 916 ADDL #8, MS_BACT(R0) ;POINT TO CHAR. BUFFER NOW
06 A0 08 B0 01DF 917 MOVW #8, MS_CNT(R0) ;STORE BYTE COUNT FOR CHAR. DATA
08 A0 00BA C5 D0 01E3 918 MOVW UCBSL_MS_TSPT2(R5), MS_MBA0(R0) ;STORE MESSAGE BUFFER ADDR.
08 A0 10 C0 01E9 919 ADDL #16, MS_MBA0(R0) ;AS CHAR. DATA
0C A0 0E B0 01ED 920 MOVW #14, MS_LNTH(R0) ;LENGTH OF CHAR. DATA=14.
OE A0 B4 01F1 921 CLRW MS_CHWD(R0) ;ZERO CHARACTERISTIC WORD
01F4 922
01F4 923
01F4 924
01F4 925
01F4 926
01F4 927
64 00BE C5 B0 01F4 928 MOVW UCBSW_MS_TSPT3(R5), (R4) ;LOAD INTO TSDB
68 A5 0400 8F A8 01F9 929 B1SW #UCBSW_MS_LBA, UCBSW_DEVSTS(R5) ;MARK LOADING MESSAGE BUFFER
05 01FF 930 ; ADDR. INTO TS11.
01FF 931 RSB ;RETURN
0200 932
0200 933

```



```
0200 935 .SBTTL TEST NBA (NEED BUFFER ADDRESS)
0200 936
0200 937 : TEST_NBA - Subroutine called from STARTIO to determine if the TS11 has
0200 938 : a valid message buffer. If YES, then we merely return. If NOT, we
0200 939 : re-establish the message buffer obtained at SYSTEM INIT time.
0200 940
0200 941 : This routine assumes that the following UCB fields were initialized
0200 942 : at UNIT INIT time:
0200 943
0200 944 : UCB$Q_MS_BUFSVAPTE
0200 945 : UCB$Q_MS_OMPR
0200 946
0200 947 : INPUTS:
0200 948 : R5 => UCB
0200 949
0200 950 : OUTPUTS:
0200 951 : Message buffer established in TS11.
0200 952
0200 953
0200 954 TEST_NBA:
009C C5 8ED0 0200 955 POPL UCB$Q_DPC(R5) ; Pop return off stack in case.
0400 8F AA 0205 956 BICW #UCB$Q_MS_LBA,- ; This bit maybe left on from INIT if
68 A5 0209 957 UCB$Q_DEVSTS(R5) ; setting of switches inside drive so
; dictate. We clear it here because
; this is a convenient place.
51 24 A5 D0 020B 960
020B 961 MOVL UCB$Q_CRB(R5),R1 ; R1 => CRB
020F 962 ASSUME IDB$Q_CSR EQ 0
54 2C B1 D0 020F 963 MOVL @CRB$Q_INTD+VEC$Q_IDB(R1),R4 ; R4 => CSR.
50 02 A4 B0 0213 964 MOVW 2(R4),R0 ; R0 contains TSSR register.
03 50 07 E0 0217 965 BBS #MS_TSSR_V_SSR,R0,10$ ; Branch to continue if TS11 ready.
009A 31 021B 966 BRW 60$ ; Branch to failure if NOT ready.
07 50 0A E0 021E 967 10$: BBS #MS_TSSR_V_NBA,R0,20$ ; Branch around if we NEED to re-
; establish message buffer address.
50 01 9A 0222 969 ; Else indicate success and
009C D5 17 0222 970 MOVZBL S^#SS$Q_NORMAL,R0 ; return to caller.
0225 971 JMP @UCB$Q_DPC(R5)
34 A1 D0 0229 972 20$: MOVL CRB$Q_INTD+VEC$Q_MAPREG(R1),-
00E8 C5 022C 973 UCB$Q_MS_TMP2(R5) ;SAVE CURRENT UBA MAP CONTEXT.
00D8 C5 D0 022F 974 MOVL UCB$Q_MS_OMPR(R5),- ; Setup to map UNIBUS just in case
34 A1 0233 975 CRB$Q_INTD+VEC$Q_MAPREG(R1)
0235 976
0235 977 ASSUME UCB$Q_BOFF EQ UCB$Q_SVAPTE+4
0235 978 ASSUME UCB$Q_BCNT EQ UCB$Q_BOFF+2
78 A5 7D 0235 979 MOVQ UCB$Q_SVAPTE(R5),-
00E0 C5 0238 980 UCB$Q_MS_TMP1(R5) ;SAVE UCB$Q_SVAPTE, W_BCNT, W_BOFF.
00EC C5 7D 023B 981 MOVQ UCB$Q_MS_BUFSVAPTE(R5),- ; Restore parameters to remap message
78 A5 023F 982 UCB$Q_SVAPTE(R5) ; buffer in UNIBUS space.
0241 983
0241 984 LOADUBA ; Reload UNIBUS map registers for
0247 985 ; message buffer.
0247 986
0247 987
0247 988 :
0247 989 : ISSUE WRITE CHARACTERISTIC COMMAND TO TELL MESSAGE BUFFER ADDR. TO TS11
0247 990 :
50 00B6 C5 D0 0247 991 MOVL UCB$Q_MS_TSPT1(R5),R0 ; R0 => command packet
```



```

      COB4 8F  B0 024C 992      MOVW  #<HC WRC!MS_CPHD_M_ACK>,-
      60      0250 993      MS_CPHD(R0)      ; Move command (WRITE CHARACTERISTICS)
      00BA C5  D0 0251 994      ; to 1ST word of command packet.
      02 A0 08  C0 0255 995      MOVL  UCBSL_MS_TSPT2(R5),-
      06 A0 08  B0 0257 996      MS_BACT(R0)      ; Store UNIBUS address of packet in
      00BA C5  D0 0258 997      ADDL  #8,MS_BACT(R0)      ; packet.
      08 A0 10  C0 025B 998      ; Update to point to CHARACTERISTICS
      0C A0 0E  B0 025B 999      MOVW  #8,MS_CNT(R0)      ; buffer beyond packet.
      0E A0 08  D0 025F 1000      MOVL  UCBSL_MS_TSPT2(R5),-
      08 A0 10  C0 0263 1001      MS_MBAO(R0)      ; Store byte count for char. data
      0C A0 0E  B0 0265 1002      ADDL  #16,MS_MBAO(R0)      ; Store UNIBUS address of PACKET
      0E A0 08  B4 0269 1003      ; into the CHARACTERISTICS data.
      0E A0 08  B4 0269 1004      MOVW  #14,MS_LNTH(R0)      ; Message BUFF is 16 beyond packet.
      0E A0 08  B4 026D 1005      CLRW  MS_CHWD(R0)      ; LENGTH OF CHAR. DATA=14.
      0E A0 08  B4 0270 1006      ; ZERO CHARACTERISTIC WORD
      0E A0 08  B4 0270 1007      ; **=>NO MESSAGE BUFFER RELEASE INTERRUPT
      0E A0 08  B4 0270 1008      ; ** NO ATTENTION INTERRUPT, AND NO
      0E A0 08  B4 0270 1009      ; ** SKIP TAPE MARKS STOP
      17 64 A5 05  E0 0276 1010      DSBINT
      64 00BE C5  B0 027B 1011      BBS  #UCBSV_POWER,UCBSW_STS(R5),30$
      09 11 0280 1012      MOVW  UCBSW_MS_TSPT3(R5),(R4) ; LOAD INTO TSDB
      09 11 028A 1013      WFIKPC 40$,#2      ; Wait for interrupt.
      09 11 0290 1014      IOFORK
      09 11 0292 1015 30$:      BRB  50$      ; Branch around powerfail branch.
      09 11 0295 1016 40$:      ENBINT
      09 11 0299 1017      SETIPL UCBSB_FIPL(R5)      ; Lower IPL in case of TIMEOUT.
      09 11 029B 1018      BRB  60$      ; Branch if we had POWERFAIL.
      09 11 029B 1019 50$:
      51 24 A5  D0 029B 1020      MOVL  UCBSL_CRB(R5),R1      ; R1 => CRB.
      00E8 C5  D0 029F 1021      MOVL  UCBSL_MS_TMP2(R5),-
      34 A1 02A3 1022      CRBSL_INTD+VECSW_MAPREG(R1)      ; Restore previous mapping context.
      00E0 C5 7D 02A5 1023      MOVQ  UCBSQ_MS_TMP1(R5),-
      78 A5 02A9 1024      UCBSL_SVAPTE(R5)      ; And also transfer parameters.
      07 00C2 C5 E0 02AB 1025      BBS  #MS_TSSR_V_NBA,-
      50 01 9A 02AD 1026      UCBSW_MS_TSSR(R5),60$      ; Test if all that had any effect
      009C D5 17 02B1 1027      MOVZBL S^#SS$_NORMAL,R0      ; by seeing if we still have NBA.
      07 00C2 C5 17 02B4 1028      JMP  @UCBSL_DPC(R5)      ; Else indicate success and
      50 0084 8F 3C 02B8 1029 60$:      ; return to caller.
      009C D5 17 02B8 1030      ; Terminate the I/O function
      50 0084 8F 3C 02B8 1031      MOVZWL #SS$ DEVOFFLINE,R0      ; by returning the OFFLINE status and
      009C D5 17 02BD 1032      JMP  @UCBSL_DPC(R5)      ; return to caller.
```



```
02C1 1034 .SBTTL START I/O OPERATION
02C1 1035 :+
02C1 1036 : TS_STARTIO - START I/O OPERATION ON DEVICE
02C1 1037 :
02C1 1038 : THIS ENTRY POINT IS ENTERED TO START AN I/O OPERATION ON TS11/TS04
02C1 1039 :
02C1 1040 : INPUTS:
02C1 1041 :
02C1 1042 : R3 = ADDRESS OF I/O PACKET.
02C1 1043 : R5 = UCB ADDRESS OF DEVICE UNIT
02C1 1044 :
02C1 1045 : OUTPUT:
02C1 1046 :
02C1 1047 : FUNCTION DEPENDENT PARAMETERS ARE STORED INTO THE DEVICE UCB,
02C1 1048 : ERROR RETRY COUNT IS RESET, AND THE FUNCTION IS EXECUTED. AT
02C1 1049 : FUNCTION COMPLETION THE OPERATION IS TERMINATED THRU REQUEST COMPLETE.
02C1 1050 :
02C1 1051 :-
02C1 1052 :
02C1 1053 TS_STARTIO: ;START I/O OPERATION
02C1 1054 .IF DF TS_TRACE
02C1 1055 BSBW TRACE_IRP ; Trace this IRP.
02C1 1056 .ENDC
02C1 1057 BSBW TEST_NBA ; Assure that TS11 has valid MESSAGE
02C4 1058 ; BUFFER.
02C4 1059 BLBS R0,5$ ; LBS implies success. GOTO continue.
02C7 1060 BRW FCNEXT ; Else branch to terminate function.
02CA 1061 5$:
02CA 1062 MOV B UCB$B_ERTMAX(R5),UCB$B_ERTCNT(R5) ;INITIALIZE ERROR RETRY COUNT
02D1 1063 MOV W IRP$W_FUNC(R3),UCB$W_FUNC(R5) ;SAVE FUNCTION CODE & MODIFIER
02D7 1064 MOV L IRP$L_MEDIA(R3),R0 ;GET PARAMETER LONGWORD
02DB 1065
02DB 1066 :
02DB 1067 : MOVE FUNCTION DEPENDENT PARAMETERS TO UCB
02DB 1068 :
02DB 1069 :
02DB 1070 EXTZV #IRP$V_FCODE,#IRP$S_FCODE,- ;EXTRACT I/O FUNCTION CODEE
02DE 1071 IRP$W_FUNC(R3),R1
02E1 1072 CMPL #IOS_SPACEFILE,R1 ;SPACE FILE FUNCTION?
02E4 1073 BEQL 10$ ;IF EQL YES
02E6 1074 CMPL #IOS_SPACERECORD,R1 ;SPACE RECORD FUNCTION?
02E9 1075 BEQL 20$ ;IF EQL YES
02EB 1076 CMPL #IOS_SETCHAR,R1 ;SET CHARACTERISTICS FUNCTION?
02EE 1077 BEQL 50$ ;IF EQL YES
02F0 1078 CMPL #IOS_AVAILABLE,R1 ;AVAILABLE function?
02F3 1079 BEQL 75$ ;IF EQL YES
02F5 1080 CMPL #IOS_READPBLK+1,R1 ;DISJOINT CODE?
02F8 1081 BGTRU 100$ ;IF GTRU NO
02FA 1082 R1,<- ;DISPATCH LOGICAL FUNCTIONS
02FA 1083 70$,- ;REWIND AND SET OFFLINE
02FA 1084 60$,- ;SET MODE
02FA 1085 80$,- ;REWIND
02FA 1086 10$,- ;SKIP FILE
02FA 1087 20$,- ;SKIP RECORD
02FA 1088 90$,- ;SENSE TAPE MODE
02FA 1089 90$,- ;WRITE EOF
02FA 1090 >,LIMIT=#IOS_REWINDOFF ;
```

FF3C 30
03 50 E8
04CB 31
0080 C5 0081 C5 90
009A C5 20 A3 B0
50 38 A3 D0
51 06 00 EF
51 20 A3
51 02 D1
51 2B 13
51 09 D1
51 32 13
51 1A D1
51 46 13
51 11 D1
51 5A 13
51 0D D1
6C 1A


```
51 06 A2 030C 1091 SUBW #IOS_READPRESET-10$_READPBLK-7,R1 ;CONVERT TO DENSE FUNCTION CODE
63 11 030F 1092 BRB 110$ ;**LAST LINE NEED BE ADJUSTED
    0311 1093
    0311 1094
    0311 1095 : SPACE FILE FUNCTION - SET SPACE COUNT AND PROPER FUNCTION
    0311 1096
    0311 1097
51 02 3C 0311 1098 10$: MOVZWL #CDHC_STF,R1 ;SET SPACE FILE FORWARD
50 B5 0314 1099 TSTW R0 ;SPACE FILE FORWARD?
12 14 0316 1100 BGTR 40$ ;IF GTR YES
51 05 9A 0318 1101 MOVZBL #CDHC_STR,R1 ;SET FOR SPACE FILE REVERSE
0A 11 031B 1102 BRB 30$
    031D 1103
    031D 1104 : SPACE RECORD FUNCTION - SET SPACE COUNT AND PROPER HARDWARE COMMAND
    031D 1105
    031D 1106
    031D 1107
51 09 9A 031D 1108 20$: MOVZBL #CDHC_SRF,R1 ;SET FOR SPACE RECORD FORWARD
50 B5 0320 1109 TSTW R0 ;SPACE RECORD FORWARD?
06 14 0322 1110 BGTR 40$ ;IF GTR YES
51 07 9A 0324 1111 MOVZBL #CDHC_SRR,R1 ;SET FOR SPACE RECORD REVERSE
50 50 AE 0327 1112 30$: MNEGW R0,R0 ;CONVERT TO POSITIVE COUNT
00B4 C5 50 B0 032A 1113 40$: MOVW R0,UCB$W_MS_SPACNT(R5) ;SET SPACE COUNT
43 12 032F 1114 BNEQ 110$ ;IF NEQ SPACING REQUIRED
51 00 9A 0331 1115 MOVZBL #CDHC_NOP,R1 ;SET FOR NO OPERATION
3E 11 0334 1116 BRB 110$
    0336 1117
```



```
0336 1119 :  
0336 1120 : SET CHARACTERISTICS FUNCTION - STORE NEW TAPE CHARACTERISTICS  
0336 1121 :  
0336 1122 : ****TS11/TS04 HAS ONLY ONE CLASS AND TYPE****  
0336 1123 :  
40 A5 38 A3 B0 0336 1124 50$: MOVW IRP$L_MEDIA(R3),UCB$B_DEVCLASS(R5) ;SET NEW DEVICE CLASS AND TYPE  
033B 1125 :  
033B 1126 :  
033B 1127 : SET MODE FUNCTION - STORE NEW TAPE MODE  
033B 1128 :  
033B 1129 :  
42 A5 3A A3 B0 033B 1130 60$: MOVW IRP$L_MEDIA+2(R3),UCB$W_DEVBUFSIZ(R5) ;SET NEW DEFAULT BUFFER SIZE  
7C A5 3C A3 B0 0340 1131 MOVW IRP$L_MEDIA+4(R3),UCB$W_BOFF(R5) ;SAVE NEW TAPE CONTROL PARAMETERS  
51 14 9A 0345 1132 MOVZBL #CDHC_SCH,R1 ;SET DISPATCH INDEX  
2A 11 0348 1133 BRB 110$ ;  
034A 1134 :  
034A 1135 :  
034A 1136 : LOGICAL REWIND AND SET TAPE OFFLINE - CONVERT TO UNLOAD COMMAND  
034A 1137 :  
034A 1138 :  
51 01 9A 034A 1139 70$: MOVZBL #CDHC_UNL,R1 ;SET FOR UNLOAD COMMAND  
25 11 034D 1140 BRB 110$ ;  
034F 1141 :  
034F 1142 :  
034F 1143 : AVAILABLE FUNCTION - Equivalent of REWIND(NOWAIT) and clear of UCB$M_VALID.  
034F 1144 :  
034F 1145 :  
034F 1146 75$:  
00A4 8F B0 034F 1147 MOVW #IOS_REWIND!IOSM_NOWAIT,-; Simulate a REWIND NOWAIT.  
009A C5 0353 1148 UCB$W_FUNC(R5)  
0800 8F AA 0356 1149 BICW #UCB$M_VALID,- ; And clear valid bit.  
64 A5 035A 1150 UCB$W_STS(R5) ; and fall thru to rewind logic.  
035C 1151 :  
035C 1152 :  
035C 1153 : LOGICAL REWIND FUNCTION - CONVERT TO PHYSICAL FUNCTION  
035C 1154 :  
035C 1155 :  
51 03 9A 035C 1156 80$: MOVZBL #CDHC_RWD,R1 ;SET FOR REWIND  
13 11 035F 1157 BRB 110$ ;  
0361 1158 :  
0361 1159 :  
0361 1160 : LOGICAL WRITE EOF OR SENSE MODE FUNCTION - CONVERT TO PHYSICAL FUNCTION  
0361 1161 :  
0361 1162 :  
51 12 A2 0361 1163 90$: SUBW #IOS_SENSEMODE-IO$_READPBLK-9,R1 ;CONVERT TO PHYSICAL****  
0E 11 0364 1164 BRB 110$ ;  
0366 1165 :  
0366 1166 :  
0366 1167 : DENSE FUNCTION CODE - CHECK FOR READ, WRITE, OR WRITECHECK FUNCTION  
0366 1168 :  
0366 1169 :  
51 0A D1 0366 1170 100$: CMPL #IOS_WRITECHECK,R1 ;DATA TRANSFER FUNCTION?  
09 1A 0369 1171 BGTRU 110$ ;IF GTRU NO  
03 009A C5 06 E1 036B 1172 BBC #IOSV_REVERSE,UCB$W_FUNC(R5),110$ ;IF CLEAR,NOT REVERSE  
51 03 A0 0371 1173 ADDW #CDHC_WKR-CDHC_WCK,R1 ;CONVERT TO REVERSE FUNCTION  
0374 1174 :  
0374 1175 :
```



```
0374 1176 : FINISH PREPROCESSING
0374 1177 :
0374 1178 :
0092 C5 51 90 0374 1179 110$: MOVB R1,UCB$B_FEX(R5) :SAVE FUNCTION DISPATCH INDEX
0379 1180 :*****NOTE ABOUT BYTE FOR INDEX
0379 1181 :
0379 1182 :
0379 1183 :CENTRAL FUNCTION DISPATCH
0379 1184 :
0379 1185 :
0379 1186 FDISPATCH:
0379 1187 MOVL UCB$L_IRP(R5),R3 :RETRIEVE ADDR. OF I/O PACKET
037D 1188 BBS #IRP$V_PHYSIO,IRP$W_STS(R3),10$ :IF SET, PHYSICAL I/O FUNCTION
0382 1189 BBS #UCB$V_VALID,UCB$W_STS(R5),10$ :IF SET, VOLUME SOFTWARE VALID
50 0254 8F 3C 0387 1190 MOVZWL #SS$ VOLINV,R0 :SET VOLUME INVALID STATUS
038C 1191 BRW FCNEXT :**NO CHANGE ON UCB$V_VALID BIT HERE**
038F 1192 :
038F 1193 :
038F 1194 : UNIT IS SOFTWARE VALID OR FUNCTION IS PHYSICAL I/O
038F 1195 :
038F 1196 :
038F 1197 10$:
54 24 A5 D0 038F 1198 MOVL UCB$L_CRB(R5),R4 :GET CSR ADDRESS INTO R4...
54 2C B4 D0 0393 1199 MOVL @CRB$C_INTD+VEC$SL_IDB(R4),R4 :
50 0092 C5 9A 0397 1200 MOVZBL UCB$B_FEX(R5),R0 :GET DISPATCH INDEX
039C 1201 CASE RO,- :DISPATCH TO COMMAND HANDLING ROUTINE
039C 1202 NOP,- :NO OPERATION
039C 1203 UNLOAD,- :REWIND & UNLOAD
039C 1204 SPCFILFOR,- :SPACE FILE FORWARD
039C 1205 REWIND,- :REWIND
039C 1206 DRVCLR,- :DRIVE CLEAR
039C 1207 SPCFILREV,- :SPACE FILE REVERSE
039C 1208 ERASE,- :ERASE
039C 1209 SPCRECREV,- :SPACE RECORD REVERSE
039C 1210 PACKACK,- :PACK ACKNOWLEDGE
039C 1211 SPCRECFOR,- :SPACE RECORD FORWARD
039C 1212 WRITECHECK,- :SIMULATED WRITECHECK
039C 1213 WRITEDATA,- :WRITE DATA FORWARD
039C 1214 READDATA,- :READ DATA FORWARD
039C 1215 WRITECHECKR,- :WRITE CHECK REVERSE
039C 1216 WRITEDATA,- :WRITE DATA(NO REVERSE)
039C 1217 READDATAR,- :READ DATA REVERSE
039C 1218 REREADN,- :REREAD DATA NEXT
039C 1219 REREADP,- :REREAD DATA PREVIOUS
039C 1220 WRITERET,- :WRITE DATA RETRY
039C 1221 READPRESET,- :SIMULATED READ PRESET
039C 1222 SETCHAR,- :SIMULATED SET CHARACTERISTIC
039C 1223 GETSTS,- :GET STATUS IMMEDIATE(SENS CHAR.)
039C 1224 WRTTMK,- :WRITE TAPE MARK
039C 1225 WRTTMKR,- :WRITE TAPE MARK RETRY
039C 1226 CLEAN,- :CLEAN
039C 1227 MSGREL,- :MESSAGE BUFFER RELEASE
039C 1228 WRITESUBS,- :WRITE SUBSYSTEM MEMEORY
039C 1229 WRITECHAR,- :WRITE CHARACTERISTICS
039C 1230 >
03D8 1231 :***NOTE INDEX OUT OF BOUND***
```



```
03D8 1233 .SBTTL NOP AND SIMULATED FUNCTIONS
03D8 1234
03D8 1235 ;
03D8 1236 ; SET CHARACTERISTIC FUNCTION
03D8 1237 ;
03D8 1238
03D8 1239 SETCHAR: ;SET CHARACTERISTIC
68 A5 02 AA 03D8 1240 BICW #UCBSM_MS_SWAP,UCBSW_DEVSTS(R5) ;CLEAR SWAP BIT 1ST
04 EF 03DC 1241 EXTZV #MT$V_FORMAT,- ;GET FORMAT FIELD
04 03DE 1242 #MT$S_FORMAT,- ;
51 7C A5 03DF 1243 UCBSW_BOFF(R5),R1 ;
51 0E B1 03E2 1244 CMPW #MT$K_NORMAL15,R1 ;IS IT INDUSTRIAL COMPATIBLE?
04 12 03E5 1245 BNEQ 5$ ;BR IF NO
68 A5 02 A8 03E7 1246 BISW #UCBSM_MS_SWAP,UCBSW_DEVSTS(R5) ;SET SWAP BIT FOR
03EB 1247 ; SUBSEQUENT IO FUNCTIONS
03EB 1248 5$:
03EB 1249
03EB 1250 ;
03EB 1251 ; NO OPERATION AND SIMULATED NON-EXISTENT TS11/TS04 HARDWARE COMMAND
03EB 1252 ;
03EB 1253
03EB 1254 PACKACK: ;PACK ACKNOWLEDGE
64 A5 0800 8F A8 03EB 1255 BISW #UCBSM_VALID,UCBSW_STS(R5) ;PACKACK implies set volume valid.
03F1 1256 NOP: ;NO OPERATION
03F1 1257 WRITECHECK: ;SIMULATED WRITECHECK
03F1 1258 WRITECHECKR: ;SIMULATED WRITECHECK REVERSE
03F1 1259 READPRESET: ;READ IN PRESET
03F1 1260
03F1 1261 EXHC 10$ ;EXECUTE HARDWARE COMMAND, IF ANY
03F6 1262 10$:
039C 31 03F6 1263 BRW FCNEXT ;GOTO FUNCTION EXIT
03F9 1264 ;10$ AS RETRIABLE ERROR OCCURRED
03F9 1265 ;NO RETRIABLE ERROR, NOP ALWAYS SUCCESSFUL
03F9 1266
```



```
03F9 1268 .SBTTL READ HARDWARE FUNCTIONS
03F9 1269
03F9 1270 :
03F9 1271 : READ HARDWARE FUNCTIONS
03F9 1272 :
03F9 1273
03F9 1274 READDATA:
03F9 1275 EXHC 10$ ;READ DATA FORWARD
00B0 C5 D6 03FE 1276 INCL UCB$$_RECORD(R5) ;EXECUTE HARDWARE COMMAND
0390 31 0402 1277 BRW FCNEXT ;INCREMENT RECORD COUNT
0405 1278 ;GOTO SUCCESSFUL RETURN
0405 1279 10$: ;10$ HANDLES RETRIABLE ERRORS
0405 1280 PUSH R0 ;SAVE R0 HAS TCC
07000000 GF 16 0407 1281 JSB G^ERL$DEVICERR ;LOG BEFORE RETRY
50 8ED0 040D 1282 POPL R0 ;RESTORE
0410 1283 20$:
50 04 D1 0410 1284 CMPL #TCC_REM,R0 ;DID TAPE MOVED
15 13 0413 1285 BEQL 22$ ;YES BRANCH
00B0 C5 97 0415 1286 DECB UCB$$_ERTCNT(R5) ;ANY RETRIES REMAINING?
24 19 0419 1287 BLSS 30$ ;NO, GO AS FATAL
00B0 C5 D6 041B 1288 EXHC 20$ HC RDN ;DO READ AGAIN
036B 31 0423 1289 INCL UCB$$_RECORD(R5) ;INCREMENT RECORD COUNT
0427 1290 BRW RFCNEXT ;SUCCEED, RETURN
042A 1291 22$:
00B0 C5 97 042A 1292 DECB UCB$$_ERTCNT(R5) ;ANY RETRIES REMAINING?
OF 19 042E 1293 BLSS 30$ ;NO, GO AS FATAL ERROR
0430 1294 EXHC 22$ HC RRP ;DO REREAD PREVIOUS
00B0 C5 D6 0438 1295 INCL UCB$$_RECORD(R5) ;INCREMENT RECORD COUNT
0356 31 043C 1296 BRW RFCNEXT ;SUCCEED, RETURN
043F 1297 30$:
0000077A EF 17 043F 1298 JMP FATALERO
0445 1299
0445 1300 :
0445 1301 : REREAD PREVIOUS (SPACE REV,READ FWD)
0445 1302 :
0445 1303
0445 1304 REREADP:
0445 1305 EXHC 10$ ;REREAD DATA PREVIOUS
0348 31 044A 1306 BRW FCNEXT ;SUCCESS RETURN
044D 1307 10$:
032A 31 044D 1308 BRW FATALERO ;TREATED AS FATAL AS NOW
0450 1309
0450 1310 :
0450 1311 : READ PREVIOUS
0450 1312 :
0450 1313
0450 1314 READDATA:
0450 1315 EXHC 10$ ;READ DATA REVERSE
00B0 C5 D7 0455 1316 DECL UCB$$_RECORD(R5) ;DECREMENT RECORD COUNT
0339 31 0459 1317 BRW FCNEXT ;*NOTE*TMK PROBLEM???
045C 1318 10$: ;DO SUCCESSFUL RETURN
045C 1319 PUSH R0 ;RETRIABLE
07000000 GF 16 045E 1320 JSB G^ERL$DEVICERR ;SAVE R0 WHICH HAS TCC CODE
50 8ED0 0464 1321 POPL R0 ;LOG BEFORE RETRY
0467 1322 ;RESTORE
50 04 D1 0467 1323 20$:
0467 1324 CMPL #TCC_REM,R0 ;TAPE MOVED?
```



```
0080 15 13 046A 1325 BEQL 22$ ;YES
      C5 97 046C 1326 DECB UCB$B_ERTCNT(R5) ;ANY RETRIES LEFT?
      24 19 0470 1327 BLSS 30$ ;NO, AS FATAL ERROR
00B0 C5 D7 0472 1328 EXHC 20$ HC RDP ;DO READ DATA PREVIOUS AGAIN
      0314 31 047A 1329 DECL UCB$L_RECORD(R5) ;DECREMENT RECORD COUNT
      31 047E 1330 BRW RFCNEXT ;SUCCESS RETURN
      0481 1331 22$:
0080 C5 97 0481 1332 DECB UCB$B_ERTCNT(R5) ;ANY RETRIES LEFT?
      OF 19 0485 1333 BLSS 30$ ;NO, AS FATAL ERROR
      0487 1334 EXHC 22$ HC RRN ;DO REREAD DATA NEXT
00B0 C5 D7 048F 1335 DECL UCB$L_RECORD(R5) ;DECREMENT RECORD COUNT
      02FF 31 0493 1336 BRW RFCNEXT ;SUCCESS RETURN
      0496 1337 30$:
      0496 1338 BRW FATALERO
      0499 1339
      0499 1340
      0499 1341 ;
      0499 1342 ; REREAD DATA NEXT(SPACE FWD, READ REV)
      0499 1343 ;
      0499 1344
      0499 1345 REREADN:
      0499 1346 EXHC 10$ ;REREAD DATA NEXT
02F4 31 049E 1347 BRW FCNEXT ;SUCCESS RETURN
      04A1 1348 10$:
02D6 31 04A1 1349 BRW FATALERO ;AS FATAL ERROR AS NOW
      04A4 1350
      04A4 1351
```



```
04A4 1353 .SBTTL WRITE FUNCTIONS
04A4 1354
04A4 1355 :
04A4 1356 : WRITE DATA
04A4 1357 :
04A4 1358
04A4 1359 WRITEDATA:
46 A5 08 AA 04A4 1360 BICW #<MTSM_HWL>@-16,UCBSL_DEV :WRITE DATA FORWARD
04A8 1361 :DEPEND+2(R5) :CLEAR
04A8 1362 EXHC 10$ :HARDWARE WRITE LOCK BIT
00B0 C5 D6 04AD 1363 INCL UCBSL_RECORD(R5) :INCREMENT RECORD COUNT
02E1 31 04B1 1364 BRW FCNEXT :TAKE FUNCTION EXIT
04B4 1365 10$:
50 DD 04B4 1366 PUSHL R0 :SAVE R0
00000000 GF 16 04B6 1367 JSB G^ERL$DEVICERR :LOG BEFORE RETRY
50 BED0 04BC 1368 POPL R0 :RESTORE
04BF 1369 20$:
50 04 D1 04BF 1370 CMPL #TCC_REM,R0 :TAPE MOVED?
15 13 04C2 1371 BEQL 22$ :YES
00B0 C5 97 04C4 1372 DECB UCBSB_ERTCNT(R5) :ANY RETRIES LEFT?
24 19 04C8 1373 BLSS 30$ :NO, AS FATAL ERROR
04CA 1374 EXHC 20$,HC WRD :YES, DO WRITE AGAIN
00B0 C5 D6 04D2 1375 INCL UCBSL_RECORD(R5) :INCREMENT RECORD COUNT
02BC 31 04D6 1376 BRW RFCNEXT :TAKE SUCCESS RETURN
04D9 1377 22$:
00B0 C5 97 04D9 1378 DECB UCBSB_ERTCNT(R5) :ANY RETRIES LEFT?
OF 19 04DD 1379 BLSS 30$ :NO, FATAL
04DF 1380 EXHC 22$,HC WDR :DO WRITE DATA RETRY
00B0 C5 D6 04E7 1381 INCL UCBSL_RECORD(R5) :INCREMENT RECORD COUNT
02A7 31 04EB 1382 BRW RFCNEXT :SUCCESS RETURN
04EE 1383 30$:
0289 31 04EE 1384 BRW FATALERO
04F1 1385
04F1 1386 :
04F1 1387 : WRITE DATA RETRY(SPACE REV,ERASE,WRITE DATA)
04F1 1388 :
04F1 1389
04F1 1390 WRITERET:
04F1 1391 EXHC 10$ :WRITE DATA RETRY
029C 31 04F6 1392 BRW FCNEXT :TAKE SUCCESS RETURN
04F9 1393 10$:
027E 31 04F9 1394 BRW FATALERO :AS FATAL
04FC 1395
04FC 1396 :
04FC 1397 : WRITE SUBSYSTEM MEMORY
04FC 1398 :
04FC 1399
04FC 1400 WRITESUBS:
04FC 1401 EXHC 10$ :WRITE SUBSYSTEM MEMORY
0291 31 0501 1402 BRW FCNEXT :SUCCESS RETURN
0504 1403 10$:
0504 1404
0273 31 0504 1405 BRW FATALERO
0507 1406
0507 1407 :
0507 1408 : WRITE CHARACTERISTICS
0507 1409 : USED TO TELL SUBSYSTEM MSG BUFFER ADDR. & SET CHARACTERISTIC WORD
```


TSDRIVER
V04-000

- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00
WRITE FUNCTIONS 5-SEP-1984 00:18:15 [DRIVER.SRC]TSDRIVER.MAR;1

Page 30
(2)

```
0507 1410 ;  
0507 1411 ;  
0507 1412 WRITECHAR: ;WRITE CHARACTERISTICS  
0507 1413 ;  
0507 1414 EXHC 10$ ;  
0286 31 050C 1415 BRW FCNEXT ;SUCCESS RETURN  
050F 1416 10$:  
0268 31 050F 1417 BRW FATALERO ;  
0512 1418
```



```
0512 1420 .SBTTL POSITIONING FUNCTIONS
0512 1421
0512 1422
0512 1423 : SPACE FILE FORWARD
0512 1424 : NOTE: HARDWARE SKIPFILE COMMAND IS NOT USED.
0512 1425 : SKIPFILE IS SIMULATED BY A SERIES SKIPRECORD COMMANDS.
0512 1426
0512 1427
0512 1428 SPCFILFOR: ;SPACE FILE FORWARD
0512 1429 MOVW UCB$W_MS_SPACNT(R5),UCB$W_BOFF(R5) ;SAVE NO. OF
7C A5 00B4 C5 B0 0518 1430 MOVW UCB$W_MS_SPACNT(R5),UCB$W_BCNT(R5) ; TAPE MARKS TO SKIP
7E A5 00B4 C5 B0 051E 1431 MOVL UCB$L_RECORD(R5),UCB$L_MS_PMPR(R5) ;SAVE TAPE POSITION
00D0 C5 00B0 C5 D0 0525 1432 BSW #UCB$M_MS_SWE,UCB$W_DEVSTS(R5) ;USE OLD TAPE POSITION IF POWERFAIL
68 A5 0040 8F A8 052B 1433 ;**SOFTWARE EMULATED FUNCTION**
052B 1434 0$:
68 A5 01 AA 052B 1435 BICW #UCB$M_MS_FEF,UCB$W_DEVSTS(R5) ;CLEAR FLAG FOR 1ST EOF SEEN
052F 1436 1$:
00B4 C5 7FFF 8F B0 052F 1437 MOVW #^X7FFF,UCB$W_MS_SPACNT(R5) ;SKIP 32,768 RECORDS INSTEAD
0536 1438 EXHC 10$,HC STF ;DO IT
51 00C4 C5 3C 053E 1439 MOVZWL UCB$W_MS_XC(R5),R1 ;GET NO. OF RECORDS PASSED
00B0 C5 51 C0 0543 1440 ADDL R1,UCB$L_RECORD(R5) ;ADD IT
DE 44 A5 11 E1 0548 1441 BBC #MT$V_EOF,UCB$L_DEVDEPEND(R5),0$ ;BR IF DIDN'T SEE TAPE MARK
7E A5 B7 054D 1442 DECW UCB$W_BCNT(R5) ;DECREMENT TAPE MARK PASSED
13 E1 0550 1443 BBC #DEV$V_MNT,- ;BR IF NOT MOUNTED
05 38 A5 0552 1444 UCB$L_DEVCHAR(R5),2$
18 E1 0555 1445 BBC #DEV$V_FOR,- ;BR IF MOUNTED NOT FOREIGN
34 38 A5 0557 1446 UCB$L_DEVCHAR(R5),5$
055A 1447 2$:
2B 68 A5 00 E1 055A 1448 BBC #UCB$V_MS_FEF,UCB$W_DEVSTS(R5),4$ ;BR IF 1ST TMK
00C4 C5 01 B1 055F 1449 CMPW #1,UCB$W_MS_XC(R5) ;**1 RECORD=TAPE MARK??**
28 12 0564 1450 BNEQ 5$ ;BR IF NO
00B4 C5 01 B0 0566 1451 MOVW #1,UCB$W_MS_SPACNT(R5) ;SKIP 1 TMK REVERSE
056B 1452 EXHC 10$,HC STR
7E A5 B6 0573 1453 INCW UCB$W_BCNT(R5) ;BACKUP 1 TMK PASSED
00B0 C5 D7 0576 1454 DECL UCB$L_RECORD(R5) ;UPDATE TAPE POSITION
50 09A0 8F 3C 057A 1455 MOVZWL #$$$_ENDOFVOLUME,R0 ;YES, DOUBLE TMKS=ENDOFVOLUME
00C4 C5 7C A5 7E A5 A3 057F 1456 SUBW3 UCB$W_BCNT(R5),UCB$W_BOFF(R5),UCB$W_MS_XC(R5) ;GET NO. OF
0587 1457 ; TAPE MARKS PASSED
020B 31 0587 1458 BRW FCNEXT ;GO EXIT
68 A5 01 A8 058A 1459 4$:
058A 1460 BSW #UCB$M_MS_FEF,UCB$W_DEVSTS(R5) ;SET 1ST EOF
058E 1461 5$:
7E A5 B5 058E 1462 TSTW UCB$W_BCNT(R5) ;PASSED ALL TAPE MARKS
9C 12 0591 1463 BNEQ 1$ ;NO, GO BACK
00C4 C5 7C A5 B0 0593 1464 MOVW UCB$W_BOFF(R5),UCB$W_MS_XC(R5) ;YES,COPY TMKS PASSED
01F9 31 0599 1465 BRW FCNEXT ;GO EXIT
01DB 31 059C 1466 10$:
059C 1467 BRW FATALERO ;TAKE FAILURE RETURN
059F 1468
059F 1469
059F 1470 : SPACEFILE REVERSE
059F 1471
059F 1472
059F 1473 SPCFILREV: ;SPACE FILE REVERSE
7C A5 00B4 C5 B0 059F 1474 MOVW UCB$W_MS_SPACNT(R5),UCB$W_BOFF(R5) ;SAVE NO. OF
7E A5 00B4 C5 B0 05A5 1475 MOVW UCB$W_MS_SPACNT(R5),UCB$W_BCNT(R5) ; TAPE MARKS TO SKIP
00D0 C5 00B0 C5 D0 05AB 1476 MOVL UCB$L_RECORD(R5),UCB$L_MS_PMPR(R5) ;SAVE TAPE POSITION
```



```
68 A5 0040 8F A8 05B2 1477 BISW #UCBSM_MS_SWE,UCBSW_DEVSTS(R5) ;USE OLD TAPE POSITION IF POWERFAIL
                                05B8 1478 ;**SOFTWARE EMULATED FUNCTION**
                                05B8 1479 1$:
00B4 C5 7FFF 8F B0 05B8 1480 MOVW #^X7FFF,UCBSW_MS_SPACNT(R5) ;SKIP 32,768 RECORDS INSTEAD
                                05BF 1481 EXHC 10$,HC_SRR ;DO IT
                                E0 05C7 1482 BBS #MT$V_BOT,- ; If we ran into BOT, treat as if
                                05C9 1483 UCBSL_DEVDEPEND(R5),5$ ; we were done.
                                3C 05CC 1484 MOVZWL UCBSW_MS_XC(R5),R1 ;GET NO. OF RECORDS PASSED
                                C2 05D1 1485 SUBL R1,UCBSL_RECORD(R5) ;SUBTRACT
                                DD 44 A5 11 E1 05D6 1486 BBC #MT$V_EOF,UCBSL_DEVDEPEND(R5),1$ ;BR IF DIDN'T SEE TAPE MARK
                                7E A5 B7 05DB 1487 DECW UCBSW_BCNT(R5) ;DECREMENT TAPE MARK PASSED
                                7E A5 B5 05DE 1488 TSTW UCBSW_BCNT(R5) ;PASSED ALL TAPE MARKS?
                                D5 12 05E1 1489 BNEQ 1$ ;NO, BR BACK
                                05E3 1490 5$:
                                7E A5 A3 05E3 1491 SUBW3 UCBSW_BCNT(R5),- ; Calculate number of tape
                                7C A5 05E6 1492 UCBSW_BOFF(R5),- ; marks passed.
                                00C4 C5 05E8 1493 UCBSW_MS_XC(R5)
                                01A7 31 05EB 1494 BRW FCNEXT ;GO EXIT
                                0189 31 05EE 1495 10$:
                                05F1 1496 BRW FATALERO
                                05F1 1497
                                05F1 1498 ; SPACE RECORD FORWARD
                                05F1 1499
                                05F1 1500
                                05F1 1501
                                05F1 1502 SPCRECFOR: ;SPACE RECORD FORWARD
                                05F1 1503 EXHC 10$
                                SC 44 A5 11 E1 05F6 1504 BBC #MT$V_EOF,UCBSL_DEVDEPEND(R5),8$ ;BR IF NO TMK
                                00C4 C5 01 B1 05FB 1505 CMPW #1,UCBSW_MS_XC(R5) ;**1 RECORD=TMK?**
                                55 12 0600 1506 BNEQ 8$ ;BR IF NO
                                13 E1 0602 1507 BBC #DEV$V_MNT,- ;BR IF NOT MOUNTED
                                05 38 A5 0604 1508 UCBSL_DEVCHAR(R5),2$
                                18 E1 0607 1509 BBC #DEV$V_FOR,- ;BR IF MOUNTED NOT FOREIGN
                                4B 38 A5 0609 1510 UCBSL_DEVCHAR(R5),8$
                                00B0 C5 D5 060C 1511 2$:
                                45 13 0610 1512 TSTL UCBSL_RECORD(R5) ;WAS AT BOT?
                                00B4 C5 01 B0 0612 1513 BEQL 8$ ;BR IF YES
                                0617 1514 MOVW #1,UCBSW_MS_SPACNT(R5) ;SKIP 1 RECORD REVERSE
                                00B4 C5 01 B0 061F 1515 EXHC 10$,HC_SRR
                                0624 1516 MOVW #1,UCBSW_MS_SPACNT(R5) ;SKIP 1 RECORD REVERSE
                                00B4 C5 01 B0 062C 1517 EXHC 10$,HC_SRR
                                0631 1518 MOVW #1,UCBSW_MS_SPACNT(R5) ;SKIP 1 RECORD FORWARD
                                0C 44 A5 11 E1 0639 1519 EXHC 10$,HC_SRF
                                50 09A0 8F 3C 063E 1520 BBC #MT$V_EOF,UCBSL_DEVDEPEND(R5),6$ ;BR IF NO TMK
                                00C4 C5 B4 0643 1521 MOVZWL #$$$_ENDOFVOLUME,R0 ;WAS AT ENDOFVOLUME
                                014B 31 0647 1522 CLRW UCBSW_MS_XC(R5) ;NO RESULTANT MOVEMENT
                                064A 1523 BRW FCNEXT ;RETURN
                                00B4 C5 01 B0 064A 1524 6$:
                                064A 1525 MOVW #1,UCBSW_MS_SPACNT(R5) ;SKIP 1 RECORD FORWARD
                                064F 1526 EXHC 10$,HC_SRF
                                0657 1527 8$:
                                51 00C4 C5 3C 0657 1528 MOVZWL UCBSW_MS_XC(R5),R1 ;GET NO. OF RECORDS PASSED
                                00B0 C5 51 C0 065C 1529 ADDL R1,UCBSL_RECORD(R5) ;UPDATE
                                0131 31 0661 1530 BRW FCNEXT
                                0113 31 0664 1531 10$:
                                0664 1532 BRW FATALERO
                                0667 1533
```



```
0667 1534 :  
0667 1535 : SPACE RECORD REVERSE  
0667 1536 :  
0667 1537 :  
0667 1538 SPCRECREV: ;SPACE RECORD REVERSE  
0667 1539 EXHC 10$ ;  
066C 1540 BBS #MTSV_BOT,- ; If we ran into BOT, treat as if  
066E 1541 UCB$[DEVDEPEND(R5),5$ ; we were done.  
51 0A 44 A5 3C 0671 1542 MOVZWL UCB$[MS_XC(R5),R1 ;GET NO. OF RECORDS PASSED  
00B0 C5 51 C2 0676 1543 SUBL R1,UCB$[RECORD(R5) ;UPDATE  
0117 31 067B 1544 5$: BRW FCNEXT ;  
00F9 31 067E 1545 10$: BRW FATALERO ;  
067E 1546  
0681 1547  
0681 1548  
0681 1549 : REWIND  
0681 1550 :  
0681 1551 :  
0681 1552  
0681 1553 REWIND: ;REWIND  
0681 1554 EXHC 10$  
46 A5 01 A8 0686 1555 BSW #<MTSM_BOT@-16>,UCB$[DEVDEPEND+2(R5) ;MARK BOT  
46 A5 10 AA 068A 1556 BICW #<MTSM_LOST@-16>,UCB$[DEVDEPEND+2(R5) ;CLEAR POSITION-LOST  
00B0 C5 D4 068E 1557 CLRL UCB$[RECORD(R5)  
0100 31 0692 1558 BRW FCNEXT  
00E2 31 0695 1559 10$: BRW FATALERO  
0695 1560  
0698 1561
```



```
0698 1563 .SBTTL FORMAT COMMANDS
0698 1564
0698 1565 ;
0698 1566 ; WRITE TAPE MARK
0698 1567 ;
0698 1568
0698 1569 WRTTMK: ;WRITE TAPE MARK
46 A5 08 AA 0698 1570 BICW #<MTSM_HWL>@-16,UCBSL_DEVDEPEND+2(R5) ;CLEAR
069C 1571 ; WRITE LOCK BIT FIRST
069C 1572 EXHC 10$ ;
00B0 C5 D6 06A1 1573 INCL UCBSL_RECORD(R5) ;INCREMENT RECORD COUNT
00ED 31 06A5 1574 BRW FCNEXT ;GOTO EXIT
50 DD 06A8 1575 10$: PUSHL R0 ;SAVE R0
00000000 GF 16 06AA 1577 JSB G^ERL$DEVICERR ;LOG BEFORE RETRY
50 BED0 06B0 1578 POPL R0 ;RESTORE
50 04 D1 06B3 1579 20$: CMPL #TCC_REM,R0 ;TAPE MOVED?
15 13 06B6 1580 BEQL 22$ ;YES
00B0 C5 97 06B8 1582 DECB UCBSB_ERTCNT(R5) ;ANY RETRIES LEFT?
24 19 06BC 1583 BLSS 30$ ;NO, FATAL
06BE 1584 EXHC 20$,HC WTM ;DO IT AGAIN
00B0 C5 D6 06C6 1585 INCL UCBSL_RECORD(R5) ;INCREMENT RECORD COUNT
00C8 31 06CA 1586 BRW RFCNEXT ;RETURN
06CD 1587 22$: DECB UCBSB_ERTCNT(R5) ;ANY RETRIES LEFT?
00B0 C5 97 06CD 1588 BLSS 30$ ;NO, FATAL
OF 19 06D1 1589 EXHC 22$,HC WTR ;DO WRITE TAPE MARK RETRY
00B0 C5 D6 06DB 1591 INCL UCBSL_RECORD(R5) ;INCREMENT RECORD COUNT
00B3 31 06DF 1592 BRW RFCNEXT ;
06E2 1593
0095 31 06E2 1594 30$: BRW FATALERO ;BRANCH FATAL ERROR
06E5 1595 ;
06E5 1596 ; WRITE TAPE MARK RETRY(SPACE REV,ERASE,WRITE TAPE MARK)
06E5 1597 ;
06E5 1598
06E5 1599 WRTTMKR: ;WRITE TAPE MARK RETRY
00A8 31 06E5 1600 EXHC 10$ ;
06EA 1601 BRW FCNEXT ;GO EXIT
00BA 31 06ED 1602 10$: BRW FATALERO ;FATAL AS NOW
06F0 1604 ;
06F0 1605 ; ERASE
06F0 1606 ;
06F0 1607
06F0 1608 ERASE: ;ERASE
06F0 1609 EXHC 10$ ;
009D 31 06F5 1610 BRW FCNEXT ;
007F 31 06F8 1611 10$: BRW FATALERO ;
06FB 1613
```

```

06FB 1615 .SBTTL CONTROL COMMANDS
06FB 1616
06FB 1617 ;
06FB 1618 ; CONTROL COMMANDS
06FB 1619 ;
06FB 1620
06FB 1621 MSGREL: ;MESSAGE BUFFER RELEASE
0092 31 06FB 1622 EXHC 10$
0700 1623 BRW FCNEXT
0703 1624 10$:
0703 1625
0074 31 0703 1626 BRW FATALERO
0706 1627
0706 1628 UNLOAD: ;
0706 1629 EXHC 10$
070B 1630 BRW FCNEXT
0087 31 070E 1631 10$:
0069 31 070E 1632 BRW FATALERO
0711 1633
0711 1634 CLEAN: ;CLEAN
0711 1635 EXHC 10$
0716 1636 BRW FCNEXT
007C 31 0719 1637 10$:
005E 31 0719 1638 BRW FATALERO
071C 1639

```



```
071C 1641 .SBTTL .INITIALIZE AND GET STATUS
071C 1642
071C 1643 :
071C 1644 : DRIVE INITIALIZE
071C 1645 :
071C 1646
071C 1647 DRVCLR: ;DRIVE INITIALIZE
071C 1648 EXHC 10$
0071 31 0721 1649 BRW FCNEXT
0724 1650 10$:
0053 31 0724 1651 BRW FATALERO
0727 1652
0727 1653 :
0727 1654 : GET STATUS (END MESSAGE ONLY)
0727 1655 :
0727 1656
0727 1657 GETSTS:
0727 1658 EXHC 10$
46 A5 0F AA 072C 1659 BICW #<MTSM_BOT!- ;CLEAR BITS IN UCBSL_DEVDEPEND+2
0730 1660 MTSM_EOF!-
0730 1661 MTSM_EOT!- ;END OF TAPE
0730 1662 MTSM_HWL>a-16,UCBSL_DEVDEPEND+2(R5) ;
0730 1663 BBC #MS_XSRO_V BOT,- ;AT BOT?
0C 00FE 01 E1 0732 1664 UCBSW_MS_XSRO(R5),1$ ;BR IF NO
00B0 C5 D4 0736 1665 CLRL UCBSL_RECORD(R5) ;CLEAR RECORD COUNT
46 A5 01 A8 073A 1666 BISW #<MTSM_BOTa-16>,UCBSL_DEVDEPEND+2(R5) ;SET BOT
46 A5 10 AA 073E 1667 BICW #<MTSM_LOSTa-16>,UCBSL_DEVDEPEND+2(R5) ;CLEAR LOST BIT
0742 1668 1$:
04 00FE 0F E1 0742 1669 BBC #MS_XSRO_V TMK,- ;AT TAPE MARK
46 A5 02 A8 0744 1670 UCBSW_MS_XSRO(R5),2$ ;BR IF NO
0748 1671 BISW #<MTSM_EOFa-16>,UCBSL_DEVDEPEND+2(R5) ;SET EOF
074C 1672 2$:
04 00FE 02 E1 074C 1673 BBC #MS_XSRO_V WLK,- ;WRITE-LOCKED?
46 A5 08 A8 074E 1674 UCBSW_MS_XSRO(R5),3$ ;BR IF NO
0752 1675 BISW #<MTSM_HOLA-16>,UCBSL_DEVDEPEND+2(R5) ;SET WRITE-LOCKED
0756 1676 3$:
0D 00FE 00 E1 0756 1677 BBC #MS_XSRO_V EOT,- ;END OF TAPE
46 A5 10 AA 0758 1678 UCBSW_MS_XSRO(R5),4$ ;BR IF NO
46 A5 04 A8 075C 1679 BICW #<MTSM_LOSTa-16>,UCBSL_DEVDEPEND+2(R5) ;CLEAR POS.LOST
50 0878 8F 3C 0760 1680 BISW #<MTSM_EOTA-16>,UCBSL_DEVDEPEND+2(R5) ;SET END OF TAPE
0764 1681 MOVZWL #SS$_ENDOF TAPE,R0 ;PUT IN RETURN STATUS
0769 1682 4$:
05 00FE 06 E0 0769 1683 BBS #MS_XSRO_V ONL,- ;CHECK IF ONLINE?
076B 1684 UCBSW_MS_XSRO(R5),6$ ;BR IF YES
076F 1685
50 01A4 8F 3C 076F 1686 MOVZWL #SS$_MEDOFL,R0 ;RETURN MEDIUM-OFFLINE
0774 1687 6$:
001E 31 0774 1688 BRW FCNEXT
0777 1689 10$:
0000 31 0777 1690 BRW FATALERO ;TREAT AS FATAL
077A 1691
```

```
077A 1693 .SBTTL COMPLETION PROCESSING
077A 1694 :
077A 1695 : FATALERR - FINISHING UP THE I/O REQUEST PROCESSING WHEN THE OPERATION
077A 1696 : ENDS WITH FATAL OR HARD ERROR.
077A 1697 : R0 HAS THE FINAL STATUS CODE ALREADY.
077A 1698 :
077A 1699 :
077A 1700 FATALERO: ;NO ERROR CODE IN R0
50 008C 8F 3C 077A 1701 MOVZWL #SS$_DRVERR,R0 ;GIVE IT ONE FOR NOW
00C4 C5 B4 077F 1702 FATALERR: ;
077F 1703 CLRW UCBSW_MS_XC(R5) ;MAKE SURE NOTHING XFERRED/SKIPPED
0783 1704 :
50 01A4 8F B1 0783 1705 CMPW #SS$ MEDOFL,R0 ; See if error is MEDIA OFF LINE.
0B 13 0788 1706 BEQL FCNEXT ; If so, then branch around logging error.
50 DD 078A 1707 PUSHL R0 ;SAVE FINAL STATUS
00000000 GF 16 078C 1708 JSB G^ERL$DEVICERR ;LOG DEVICE ERROR
50 8ED0 0792 1709 POPL R0 ;
0795 1710 RFCNEXT: ;SUCCESS RETURN AFTER RETRY
0795 1711 FCNEXT:
68 A5 0840 8F AA 0795 1712 BICW #<UCBSM_MS_RPI!UCBSM_MS_SWE>,UCBSW_DEVSTS(R5) ;ASSURE FLAGS CLEARED
50 DD 079B 1713 PUSHL R0 ;SAVE FINAL STATUS
00000000 GF 16 079D 1714 JSB G^IOC$DIAGBUFILL ;FILL DIAGNOSTIC BUFFER IF PRESENT
02 AE 00C4 C5 B0 07A3 1715 MOVW UCBSW_MS_XC(R5),2(SP) ;SET BYTES XFERRED OR RECORDS/FILES SKIPPED
36 6E E8 07A9 1716 BLBS (SP),70$ ;IF LBS SUCCESSFUL COMPLETION
54 58 A5 D0 07AC 1717 MOVL UCBSL_IRP(R5),R4 ;GET ADDRESS OF CURRENT I/O PACKET
2D 2A A4 04 E1 07B0 1718 BBC #IRP$V_VIRTUAL,IRP$W_STS(R4),70$ ;IF CLR, NOT VIRTUAL FUNCTION
54 18 A4 D0 07B5 1719 MOVL IRP$W_WIND(R4),R4 ;GET ADDRESS OF WINDOW BLOCK
16 A4 B4 07B9 1720 CLRW UCBSW_NMAP(R4) ;CLEAR NUMBER OF MAPPING POINTERS
54 34 A5 D0 07BC 1721 MOVL UCBSL_VCB(R5),R4 ;GET ADDRESS OF VCB LISTHEAD
52 4C A5 9E 07C0 1722 MOVAB UCBSL_IOQFL(R5),R2 ;GET ADDRESS OF I/O QUEUE
53 52 D0 07C4 1723 MOVL R2,R3 ;SET ADDRESS OF PREVIOUS ENTRY
53 63 D0 07C7 1724 60$: MOVL (R3),R3 ;GET ADDRESS OF NEXT ENTRY
52 53 D1 07CA 1725 CMPL R3,R2 ;END OF LIST?
13 13 07CD 1726 BEQL 70$ ;IF EQL YES
F3 2A A3 04 E1 07CF 1727 BBC #IRP$V_VIRTUAL,IRP$W_STS(R3),60$ ;IF CLR, NOT VIRTUAL FUNCTION
53 04 A3 D0 07D4 1728 MOVL 4(R3),R3 ;RETRIEVE ADDRESS OF PREVIOUS ENTRY
51 00 B3 OF 07D8 1729 REMQUE @ (R3),R1 ;REMOVE ENTRY FROM DRIVER QUEUE
04 B4 61 OE 07DC 1730 INSQUE (R1),@4(R4) ;INSERT ENTRY IN BLOCKED I/O LIST
E5 11 07E0 1731 BRB 60$ ;
50 8ED0 07E2 1732 70$: POPL R0 ;RETRIEVE FINAL STATUS
51 44 A5 D0 07E5 1733 MOVL UCBSL_DEVDEPEND(R5),R1 ;SET MAGTAPE STATUS AND CHARACTERISTIC
07E9 1734 .IF DF TS TRACE
07E9 1735 BSBW TRACE_STATUS ; Trace final I/O status.
07E9 1736 .ENDC
07E9 1737 REQCOM ;COMPLETE REQUEST
07EF 1738
```



```
07EF 1740 .SBTTL  HARDWARE COMMAND EXECUTOR
07EF 1741 :+
07EF 1742 : HCEX - EXECUTES HARDWARE COMMAND
07EF 1743 :
07EF 1744 : THIS ROUTINE IS CALLED VIA A BSB WITH A WORD IMMEDIATELY FOLLOWING THAT
07EF 1745 : SPECIFIES THE ADDRESS OF AN (RETRIABLE) ERROR ROUTINE. ALL DATA IS ASSUMED TO HAVE
07EF 1746 : BEEN SET UP IN THE UCB BEFORE THE CALL. THE COMMAND PACKET IS APPROPRIATELY
07EF 1747 : SETUP AND INITIATED BY LOADING THE ADDR. OF COMMAND PACKET INTO THE
07EF 1748 : TS11/TS04 DEVICE REGISTER, TSDB. THEN, A WAITFOR INTERRUPT IS EXECUTED
07EF 1749 : AND WHEN THE INTERRUPT OCCURS, CONTROL IS RETURNED TO THE CALLER.
07EF 1750 : THE ROUTINE MAINLY DEALS WITH THE HARDWARE INTERFACE.
07EF 1751 :
07EF 1752 : INPUTS:
07EF 1753 : R0=HARDWARE COMMAND TABLE DISPATCH INDEX
07EF 1754 : R4=EQUIVALENT CSR ADDR. FOR TS11/TS04
07EF 1755 : R5=DEVICE UNIT UCB ADDRESS
07EF 1756 :
07EF 1757 : 00(SP) = RETURN ADDRESS OF CALLER
07EF 1758 : 04(SP) = RETURN ADDRESS OF CALLER'S CALLER
07EF 1759 :
07EF 1760 : IMMEDIATELY FOLLOWING INLINE AT THE CALL SITE IS A WORD WHICH HAS
07EF 1761 : A BRANCH DESTINATION TO AN ERROR RETRY ROUTINE, IF APPROPRIATE.
07EF 1762 : OUTPUTS:
07EF 1763 : THE DRIVE STATUS, SUCH AS BOT, EOT, ETC, ARE RECORDED IN UCB.
07EF 1764 :
07EF 1765 : THERE ARE THREE EXITS FROM THIS ROUTINE:
07EF 1766 : 1) NORMAL RETURN,
07EF 1767 : 2) FATAL OR HARD ERROR EXIT, AND
07EF 1768 : 3) RETRIABLE ERROR RETURN.
07EF 1769 : WHEN EXITS, R0 HAS THE FINAL STATUS CODE IF NORMAL OR FATAL,
07EF 1770 : R0 HAS TERMINATION CODE, 4 OR 5, IF RETRIABLE.
07EF 1771 : THE DRIVE STATUS IS RECORDED INTO UCB WHILE PROCESSING TERMINATION CODE
07EF 1772 :
07EF 1773 :
07EF 1774 : HCEX:
07EF 1775 : POPL  UCB$D_DPC(R5) ;SAVE DRIVER PC VALUE
00DC 009C C5 8ED0 07EF 1776 : MOVZBL #20,UCB$D_MS_TIMEOUT(R5) ; Initialize timeout to 20 seconds.
07EF 1777 : CLRW  UCB$B_MS_DPNR(R5) ;CLEAR DATA PATH NO. & PURGE ERROR
07EF 1778 : CLRW  UCB$D_MS_DPR(R5) ;ZERO DATAPATH REG. & FINAL MAP REG.
07EF 1779 : CLRW  UCB$W_MS_XC(R5) ;INITIALIZE COUNT
0093 00C6 C5 B4 0801 1779 : MOVW  R0,UCB$B_CEX(R5) ;SAVE CASE INDEX
51 00B6 C5 D0 0805 1780 : MOVL  UCB$D_MS_TSPT1(R5),R1 ;GET COMMAND PACKET POINTER
61 F824 CF40 B0 080A 1781 : MOVL  HCTAB[RO],MS_CPHD(R1) ;LOAD COMMAND PACKET HEAD WORD
080F 1782
```

```
10 A1 FFFF 8F B0 0815 1784 MOVW #^XXXX,MS_MHD(R1) ;MARK MSG HEAD TO ENSURE MSG BUFFER RETURNED
05 68 A5 0C E5 081B 1785 BBCC #UCB$V,MS_VCK,UCB$W_DEVSTS(R5),7$ ;BR IF NOT VOLUME CHECK
61 4000 8F A8 0820 1786 B1SW #MS_CPHD_M_CVC,MS_CPHD(R1) ;YES, FLAG TO CLEAR VOLUME CHECK
0825 1787 7$:
0825 1788 CASE RO,<- ;DISPATCH TO PROPER COMMAND ROUTINE
0825 1789 PNOP,- ;NOP
0825 1790 PMIS,- ;UNLOAD
0825 1791 PPOS,- ;SPACE FILE FORWARD
0825 1792 PPOS,- ;REWIND
0825 1793 PMIS,- ;DRIVE CLEAR
0825 1794 PPOS,- ;SPACE FILE REVERSE
0825 1795 PMIS,- ;ERASE
0825 1796 PPOS,- ;SPACE RECORD REVERSE
0825 1797 PNOP,- ;SIMULATED PACK ACKNOWLEDGE
0825 1798 PPOS,- ;SPACE RECORD FORWARD
0825 1799 PNOP,- ;SIMULATED WRITECHECK
0825 1800 PXFR,- ;WRITE DATA FORWARD
0825 1801 PXFR,- ;READ DATA FORWARD
0825 1802 PNOP,- ;SIMULATED WRITE CHECK REVERSE
0825 1803 PXFR,- ;WRITE DATA (NO REVERSE)
0825 1804 PXFRR,- ;READ DATA REVERSE
0825 1805 PXFRRD,- ;REREAD DATA NEXT
0825 1806 PXFRRD,- ;REREAD DATA PREVIOUS
0825 1807 PXFR,- ;WRITE DATA RETRY
0825 1808 PNOP,- ;SIMULATED READ PRESET
0825 1809 PNOP,- ;SIMULATED SET CHARACTERISTIC
0825 1810 PMIS,- ;GET STATUS IMMEDIATE(SENS CHAR.)
0825 1811 PMIS,- ;WRITE TAPE MARK
0825 1812 PMIS,- ;WRITE TAPE MARK RETRY
0825 1813 PMIS,- ;CLEAN
0825 1814 PMIS,- ;MESSAGE BUFFER RELEASE
0825 1815 PXFR,- ;WRITE SUBSYSTEM MEMORY
0825 1816 PWCH,- ;WRITE CHARACTERISTICS
0825 1817 >
0861 1818
```



```
0861 1820 :+PNOP - NO OPERATION ON HARDWARE FOR MANY SIMULATED FUNCTIONS
0861 1821 : THEY ARE: NOP,PACK ACKNOWLEDGE,WRITECHECK,WRITE CHECK REVERSE,
0861 1822 : READ IN PRESET,SET CHARACTERISTICS.
0861 1823 : THE ROUTINE SIMPLY RETURNS.
0861 1824 :
0861 1825 PNOP:
0861 1826 RET:
009C 50 01 3C 0861 1827 MOVZWL #SS$ NORMAL,R0 ; ALWAYS SUCCESS
C5 02 C0 0864 1828 ADDL #2,UCB$L_DPC(R5) ; ADJUST TO CORRECT RETURN
009C D5 17 0869 1829 JMP @UCB$L_DPC(R5) ; RETURN TO DRIVER
086D 1830
086D 1831
086D 1832 : PPOS - CONSTRUCT COMMAD PACKET FOR POSITIONING COMMANDS:
086D 1833 : SPACE RECORDS FORWARD, SPACE RECORDS REVERSE, SKIP TAPE MARKS FORWARD,
086D 1834 : SPACE TAPE MARKS REVERSE, AND REWIND.
086D 1835
086D 1836 PPOS:
50 03 91 086D 1837 CMPB #CDHC_RWD,R0 ; REWIND COMMAND?
2A 12 0870 1838 BNEQ 5$ ; NO
0872 1839 DSBINT ; YES, DISABLE INTERRUPTS
0878 1840 BBC #UCB$V_POWER,- ;
03 64 A5 E1 087A 1841 UCB$W_STS(R5),1$ ; Continue if NO powerfail
0090 31 087D 1842 BRW PWRFLT ; Branch around if we had POWERFAIL.
0880 1843 1$:
64 00BE C5 B0 0880 1844 MOVW UCB$W_MS_TSPT3(R5),(R4) ; LOAD COMMAND POINTER
0885 1845 WFIKPCB MSTMT,#D300 ; TIMEOUT FOR 5 MIN.'S FOR 2400 FEET TAPE
0893 1846 IOFORK ; MAKE IT FORK FIRST
0193 31 0899 1847 BRW XTC ; GO PROCESS TERMINATION CODE
089C 1848 5$:
02 A1 00B4 C5 B0 089C 1849 MOVW UCB$W_MS_SPACNT(R5),MS_BACT(R1) ; LOAD THE COUNT
00C4 C5 00B4 C5 B0 08A2 1850 MOVW UCB$W_MS_SPACNT(R5),UCB$W_MS_XC(R5) ; COPY COUNT
08A9 1851 ; FALL INTO CODE TO LOAD COMMAND
00B4 C5 3C 08A9 1852 MOVZWL UCB$W_MS_SPACNT(R5),- ; Maximum size record takes one second
00DC C5 08AD 1853 UCB$L_MS_TIMEOUT(R5) ; to skip (approximately).
00000294 8F D1 08B0 1854 CMPL #11*60,- ; Compare time to skip entire tape to
00DC C5 08B6 1855 UCB$L_MS_TIMEOUT(R5) ; time to skip this # records.
08B9 1856 BGEQ 10$ ; GEQ implies skipping small # records
0294 8F 3C 08BB 1857 MOVZWL #11*60,- ; Else use maximum time to skip whole
00DC C5 08BF 1858 UCB$L_MS_TIMEOUT(R5) ; tape.
08C2 1859 BRB 20$ ; And branch around.
00DC C5 02 C0 08C4 1860 10$: ADDL #2,UCB$L_MS_TIMEOUT(R5) ; Add in fudge factor for small skips.
08C9 1861 20$:
08C9 1862
08C9 1863 :+PMIS - CONSTRUCT COMMAND PACKET FOR FORMAT COMMANDS: WRITE TAPE MARK,
08C9 1864 : ERASE,WRITE TAPE MARK RETRY; CONTROL COMMANDS: MESSAGE BUFFER RELEASE,
08C9 1865 : UNLOAD, & CLEAN; INITIALIZE COMMAND: DRIVE INITIALIZE; AND GET STATUS
08C9 1866 : COMMAND: GET STATUS IMMEDIATE.
08C9 1867
08C9 1868 PMIS:
001F 31 08C9 1869 BRW LDTSDB ; GO LOAD DEVICE REGISTER
08CC 1870
08CC 1871 : PWCH - CONSTRUCT COMMAND PACKET FOR WRITE CHARACTERISTIC COMMAND
08CC 1872
08CC 1873 PWCH:
02 A1 00BA C5 D0 08CC 1874 MOVL UCB$L_MS_TSPT2(R5),MS_BACT(R1) ; R1 POINTS TO COMMAND PACKET
08D2 1875 ADDL #8,MS_BACT(R1) ; STORE CHAR. BUFFER ADDR.
06 A1 08 B0 08D6 1876 MOVW #8,MS_CNT(R1) ; POINT TO CHAR. BUFFER NOW
; STORE BYTE COUNT FOR CHAR. DATA
```



```
08 A1 00BA C5 D0 08DA 1877      MOVL      UCBSL_MS TSPT2(R5),MS_MBA0(R1)      ;STORE MESSAGE BUFFER ADDR.
      08 A1 10 C0 08E0 1878      ADDL      #16,MS_MBA0(R1)      ; AS CHAR. DATA
      OC A1 0E B0 08E4 1879      MOVW      #14,MS_LNTH(R1)      ;LENGTH OF CHAR. DATA=14.
      OE A1 B4 08E8 1880      CLRW      MS_CHWD(R1)      ;ZERO CHARACTERISTIC WORD
      08EB 1881      ;
      08EB 1882      ; NOW, COMMAND PACKET IS SETUP, READY TO LOAD DEVICE REGISTER
      08EB 1883      ;
      08EB 1884      ;
      08EB 1885      LDTSDDB:      ;TS11/TS04 CSR EQUIVALENT=TSDB
      08EB 1886      DSBINT      ;DISABLE INTERRUPTS
      1A 64 A5 05 E0 08F1 1887      BBS      #UCBSV_POWER,UCBSW_STS(R5),PWRFL1 ;BR IF POWERFAILED
      64 00BE C5 B0 08F6 1888      MOVW      UCBSW_MS TSPT3(R5),(R4) ;LOAD THE COMMAND POINTER
      08FB 1889      WFIKPC      MSTMOT,UCBSL_MS_TIMEOUT(R5)
      0907 1890      IOFORK      ;MAKE IT FORK FIRST
      011F 31 090D 1891      BRW      XTC      ;PROCESS TERMINATION CODE
      0910 1892      ;
      0910 1893      ;
      0910 1894      ; HERE, TREAT POWERFAIL AS TIMEOUT
      0910 1895      ;
      0910 1896      ;
      0910 1897      PWRFL1:      ;
      0910 1898      ENBINT      ;ENABLE INTERRUPTS
      02DD 31 0913 1899      BRW      MSTMO1      ;GOTO TIMEOUT ROUTINE
      0916 1900      ;
      0916 1901      ; PXFR - CONSTRUCT COMMAND PACKET FOR DATA TRANSFER COMMANDS:
      0916 1902      ; READ NEXT(FORWARD), READ PREVIOUS(REVERSE), REREAD PREVIOUS(SPACE REV, READ
      0916 1903      ; FWD), REREAD NEXT(SPACE FWD, READ REV), WRITE DATA, WRITE DATA RETRY,
      0916 1904      ; AND WRITE SUBSYSTEM MEMORY.
      0916 1905      ;
      0916 1906      PXFRRD:      ;
      0916 1907      BBC      #IOSV_OPPOSITE, -      ; REREAD COMMANDS ENTER HERE.
      091C 1908      UCBSW_FUNC(R5), 10$      ; Branch if opposite bit not set.
      61 2000 8F A8 091C 1909      BISW      #MS_CPHD_M_OPP, -      ; If its set, propogate it to the
      0A 11 0921 1910      MS_CPHD(R1)      ; command header.
      0923 1911      10$:      BRB      PXFRR      ; Then rejoin common code.
      0923 1912      ;
      0923 1913      PXFR:      ;
      68 A5 20 A8 0923 1914      BISW      #UCBSM_MS_RDPR,UCBSW_DEVSTS(R5) ;FLAG BUFFERED DATAPATH
      0927 1915      REQDPR      ;REQUEST DATAPATH
      092D 1916      PXFRR:      ;*ENTRY PT FOR READ REVERSE*
      092D 1917      ;**WHICH USES DIRECT DATA PATH**
      092D 1918      REQMPR      ;REQUEST MAP REGISTER
      0933 1919      LOADUBAA      ;LOAD MAP REGISTER
      50 09 09 7C A5 3C 0939 1920      MOVZWL      UCBSW_BOFF(R5),R0      ;GET BYTE OFFSET
      51 24 A5 D0 093D 1921      MOVL      UCBSL_CRB(R5),R1      ;GET CRB
      51 09 34 A1 F0 0941 1922      INSV      CRBSL_INTD+VECSW_MAPREG(R1),#9,#9,R0 ;INSERT HGH 9 BITS
      51 00B6 C5 D0 0947 1923      MOVL      UCBSL_MS TSPT1(R5),R1      ;GET COMMAND PACKET ADDR.
      02 A1 50 D0 094C 1924      MOVL      R0,MS_BACT(R1)      ;STORE XFR ADDR.
      06 68 A5 01 E0 0950 1925      BBS      #UCBSV_MS_SWAP,UCBSW_DEVSTS(R5),12$ ;BR IF INDUSTRI.COMP.
      0955 1926      ; (SET BY SETCHAR COMMAND)
      05 009A C5 08 E1 0955 1927      BBC      #IOSV_SWAP,UCBSW_FUNC(R5),15$ ;SWAP BIT SET??
      61 1000 8F A8 095B 1928      12$:      BISW      #MS_CPHD_M_SWB,MS_CPHD(R1) ;YES, SET IT IN CMD HEADER
      095B 1929      15$:      MOVW      UCBSW_BCNT(R5),MS_CNT(R1) ;STORE BYTE COUNT
      06 A1 7E A5 B0 0960 1931      MOVW      UCBSW_BCNT(R5),UCBSW_MS_XC(R5) ;COPY BYTE COUNT
      00C4 C5 7E A5 B0 0965 1932      DSBINT      ;DISABLE INTERRUPTS
      096B 1933
```



```
4B 64 A5 05 E0 0971 1934 BBS #UCBSV POWER,UCBSW_STS(R5),20$ ;BR IF POWERFAILED
64 00BE C5 B0 0976 1935 MOVW UCBSW_MS_TSP13(R5),(R4) ;LOAD THE COMMAND POINTER
097B 1936 WFIKPCB MSTMO,#A20 ;TIMEOUT FOR 20. SEC.'S
0985 1937 IOFORK
00000000'GF 16 098B 1938 JSB G^IOC$PURGDATAP ;PURGE DATAPATH
05 50 E8 0991 1939 BLBS R0,18$ ;BR IF NO ERROR
00C7 C5 01 90 0994 1940 MOVB #1,UCBSB_MS_PER(R5) ;MARK PURGE ERROR
26 64 A5 05 E0 0999 1942 18$: BBS #UCBSV POWER,UCBSW_STS(R5),21$ ;BR IF POWERFAILED
099E 1943 ;** WANT TO SAVE DATAPATH REG. & NO. & ETC. FOR ERRLOG
00C4 C5 00FC C5 A2 099E 1944 SUBW UCBSW_MS_RBPC(R5),UCBSW_MS_XC(R5) ;GET BYTES ACTUALLY XFERRED
00C5 C5 51 D0 09A5 1945 MOVL R1,UCBSL_MS_DPR(R5) ;GET DATA PATH REGISTER
37 A3 90 09AA 1946 MOVB CRBSL_INTD+VECSB_DATAPATH(R3),-
00C6 C5 09AD 1947 UCBSB_MS_DPN(R5) ;GET DATA PATH NO.
51 7C A5 3C 09B0 1948 MOVZWL UCBSW_BOFF(R5),R1 ;GET BYTE OFFSET
00C6 C5 95 09B4 1949 TSTB UCBSB_MS_DPN(R5) ;DATAPATH NO.=0(DIRECT)?
OD 12 09B8 1950 BNEQ 22$ ;NO
51 00FC C5 A0 09BA 1951 ADDW UCBSW_MS_RBPC(R5),R1 ;YES, REVERSE OPERATION
OB 11 09BF 1952 BRB 24$ ;SKIP AROUND
09C1 1953
09C1 1954 ;
09C1 1955 ; HERE,TREAT POWERFAIL AS TIMEOUT
09C1 1956 ;
09C1 1957
09C1 1958 20$: ENBINT ;ENABLE INTERRUPTS
09C1 1959
09C4 1960 21$: BRW MSTMO
09C4 1961
09C7 1962
09C7 1963 22$: ADDW UCBSW_MS_XC(R5),R1 ;GET FINAL ADDR. OFFSET
09C7 1964
09CC 1965 24$: ASHL #<-9>,R1,R1 ;MODULO 512
51 51 F7 8F 78 09CC 1966 MOVZWL CRBSL_INTD+VECSW_MAPREG(R3),R0 ;MOVE START MAP REG. NO.
50 34 A3 3C 09D1 1967 ADDL R0,R1 ;R1 HAS FINAL MAP REG. NO.
51 50 C0 09D5 1968 ;**R2 HAS START ADDR. OF 1ST MAP REGISTER
09D8 1969 ;**R3 HAS CRB ADDRESS
09D8 1970 ;** WHICH WERE GOTTEN FROM IOC$PURGDATAP
09D8 1971 ;LEGAL MAP REG. NO.?
51 01EF 8F B1 09D8 1972 CMPW #495,R1 ;BR IF YES
1A 14 09DD 1973 BGTR 25$ ;MAKE IT FINAL MAP REG. NO.=495
51 01EF 8F 3C 09DF 1974 MOVZWL #495,R1
00CC C5 6241 D0 09E4 1975 MOVL (R2)[R1],UCBSL_MS_FMPR(R5) ;SAVE FINAL MAP REG
00D0 C5 FC A241 D0 09EA 1976 MOVL -4(R2)[R1],UCBSL_MS_PMPR(R5) ;SAVE PREVIOUS MAP REG
00D4 C5 6241 D0 09F1 1977 MOVL (R2)[R1],UCBSL_MS_NMPR(R5) ;SAVE NEXT MAP REG(=495)
1E 11 09F7 1978 BRB 27$ ;GO AHEAD NOW
09F9 1979 25$: ;LEGAL MAP REG. NO.
00CC C5 6241 D0 09F9 1980 MOVL (R2)[R1],UCBSL_MS_FMPR(R5) ;SAVE FINAL MAP REG
00D0 C5 01 CE 09FF 1981 MNEGL #1,UCBSL_MS_PMPR(R5) ;ASSUME NO PREVIOUS MAP REG
51 50 D1 0A04 1982 CMPL R0,R1 ;WAS FINAL MAP REG. 1ST MAP REG
07 13 0A07 1983 BEQL 26$ ;YES, THERE WAS NO PREVIOUS ONE
00D0 C5 FC A241 D0 0A09 1984 MOVL -4(R2)[R1],UCBSL_MS_PMPR(R5) ;OTHERWISE,SAVE PREVIOUS MAP REG
0A10 1985 26$:
00D4 C5 04 A241 D0 0A10 1986 MOVL 4(R2)[R1],UCBSL_MS_NMPR(R5) ;SAVE NEXT MAP REG
0A17 1987 27$:
00C6 C5 95 0A17 1988 TSTB UCBSB_MS_DPN(R5) ;TEST IF DIRECT DATAPATH?
OA 13 0A1B 1989 BEQL 30$ ;YES
0A1D 1990 ;*RELEASE DATAPATH AND MAP REG.'S
```



```
68 A5 20 AA 0A1D 1991 RELDPR ;RELEASE DATA PATH
0A23 1992 BICW #UCBSM_MS_RDPR,UCBSW_DEVSTS(R5) ;CLEAR FLAG
0A27 1993 30$: RELMPR ;RELEASE MAP REGISTERS
0A2D 1995 OD 11 0A2D 1996 BRB XTC1 ;
0A2F 1997
0A2F 1998
0A2F 1999
0A2F 2000 : XTC - PROCESS TERMINATION CODE
0A2F 2001 : HERE, THE FINAL STATUS CODE IS PUT IN R0, &
0A2F 2002 : THE DRIVE STATUS IS RECORDED INTO UCB
0A2F 2003 :
0A2F 2004 :
0A2F 2005 XTC:
00C4 C5 B5 0A2F 2006 TSTW UCB$W_MS_XC(R5) ;SHOULD ANYTHING XFERRED?
07 13 0A33 2007 BEQL XTC1 ;NO, BRANCH
00C4 C5 00FC C5 A2 0A35 2008 SUBW UCB$W_MS_RBPC(R5),UCBSW_MS_XC(R5) ;GET ACTUALLY XFERRED
07 E1 0A3C 2009 XTC1: BBC #MS_XSRO_V MOT,- ;DID TAPE MOVE?
04 00FE C5 0A3E 2010 UCB$W_MS_XSRO(R5),7$ ;BR IF NO
46 A5 07 AA 0A42 2011 BICW #<MTSM BOT!- ;CLEAR BOT, AND
0A46 2012 MTSM_EOF!- ;END OF FILE,
0A46 2013 MTSM_EOF!- ;END OF FILE,
0A46 2014 MTSM_EOF!- ;END OF FILE,
0A46 2015 7$: EXTZV #MS_TSSR_V TCC,#MS_TSSR_S_TCC,- ;EXTRACT TERMINATION CODE
50 03 01 EF 0A46 2016 UCB$W_MS_TSSR(R5),R0 ;INTO R0
00C2 C5 0A49 2017 CASE R0,- ;DISPATCH TO ROUTINES
0A4D 2018 100$,- ;NORMAL TERMINATION
0A4D 2019 110$,- ;ATTENTION CONDITION
0A4D 2020 120$,- ;TAPE STATUS SLERT
0A4D 2021 130$,- ;FUNCTION REJECT
0A4D 2022 140$,- ;RECOVERABLE ERROR(TAPE MOVED)
0A4D 2023 150$,- ;RECOVERABLE ERROR(TAPE NOT MOVED)
0A4D 2024 160$,- ;UNRECOVERABLE ERROR(TAPE POSI LOST)
0A4D 2025 170$,- ;FATAL CONTROLLER ERROR
0A4D 2026
0A4D 2027 >
0A61 2028 :
0A61 2029 : FATAL CONTROLLER ERROR(TCC=7)
0A61 2030 :
0A61 2031 :
0A61 2032 170$:
50 0054 8F 3C 0A61 2033 MOVZWL #SS$_CTRLERR,R0 ;PUT IN FINAL STATUS CODE
FD16 31 0A66 2034 BRW FATALERR ;GOTO FATAL ERROR
0A69 2035
0A69 2036 :
0A69 2037 : UNRECOVERABLE ERROR(TAPE POSITION LOST)
0A69 2038 : (TCC=6)
0A69 2039 :
0A69 2040 160$:
46 A5 10 AB 0A69 2041 BISW #<MTSM_LOST@-16>,UCBSL_DEVDEPEND+2(R5) ;MARK POSITION LOST
50 008C 8F 3C 0A6D 2042 MOVZWL #SS$_DRVERR,R0 ;PUT IN FINAL STATUS CODE
06 E0 0A72 2043 BBS #MS_XSRO_V ONL,- ;CHECK IF ON-LINE
05 00FE C5 0A74 2044 UCB$W_MS_XSRO(R5),165$ ;BR IF YES
50 01A4 8F 3C 0A78 2045 MOVZWL #SS$_MEDOFFL,R0 ;NO, RETURN MEDIUM OFFLINE
FCFF 31 0A7D 2046 165$: BRW FATALERR ;
0A7D 2047
```



```
0A80 2048
0A80 2049 :
0A80 2050 : NORMAL TERMINATION
0A80 2051 : (TCC=0)
0A80 2052 :
0A80 2053 100$:
50 01 3C 0A80 2054 MOVZWL #SS$_NORMAL,R0 ;PUT IN STATUS CODE
009C C5 02 C0 0A83 2055 101$:
009C D5 17 0A83 2056 ADDL #2,UCB$_DPC(R5) ;ADJUST TO CORRECT RETURN ADDRESS
0A88 2057 JMP @UCB$_DPC(R5) ;RETURN TO DRIVER
0A8C 2058 :
0A8C 2059 :
0A8C 2060 : ATTENTION CONDITION
0A8C 2061 : DRIVE HAS UNDERGONE STATUS CHANGE SUCH AS GOING OFFLINE OR COMING ONLINE
0A8C 2062 : (TCC=1)
0A8C 2063 :
0A8C 2064 110$:
06 06 06 E1 0A8C 2065 BBC #MS_XSR0_V_ONL,- ;CHECK IF ONLINE?
00FE C5 0A8E 2066 UCB$_MS_XSR0(R5),112$ ;BR IF OFFLINE.
50 05 3C 0A92 2067 MOVZWL #TCC_REN,R0 ;BECOME ONLINE, BUT
00B3 31 0A95 2068 BRW 150$ ;SHOULDN'T HAVE BEEN OFFLINE
0A98 2069 112$: ;RETRY THE COMMAND
50 0093 C5 90 0A98 2070 MOVB UCB$_CEX(R5),R0 ; GET HARDWARE COMMAND INDEX
50 01 91 0A9D 2071 CMPB #CDHC_UNL,R0 ;WAS IT UNLOAD?
DE 13 0AA0 2072 BEQL 100$ ;YES, ITS OK
50 01A4 8F 3C 0AA2 2073 MOVZWL #SS$_MEDOFFL,R0 ;MARK AS MEDIUM OFFLINE
FCDS 31 0AA7 2074 BRW FATALERR ;GOTO FATAL ERROR
0AAA 2075 :
0AAA 2076 :
0AAA 2077 :
0AAA 2078 : TAPE STATUS ALERT
0AAA 2079 : (BITS OF INTEREST: TMK, LET, RLS, EOT, RIB, AND RLL)
0AAA 2080 : **LET BIT IS LOGICAL END OF TAPE FOR DOS, NOT USED FOR NOW**
0AAA 2081 : (TCC=2)
0AAA 2082 :
0AAA 2083 : The reverse into BOT must return the status SS$_NORMAL because
0AAA 2084 : at this time BACKUP depends on this fact and that is how the
0AAA 2085 : other tape drivers work. This has been modified again. So that the
0AAA 2086 : read reverse which BAKCUP doesn't depend on returns SS$_ENDOFFILE
0AAA 2087 : when it encounters the BOT marker.
0AAA 2088 :
0AAA 2089 120$:
16 00 00 E1 0AAA 2090 BBC #MS_XSR3_V_RIB,- ;REVERSE INTO BOT?
0104 C5 0AAC 2091 UCB$_MS_XSR3(R5),121$ ;
46 A5 01 A8 0AB0 2092 BISW #<MTSM_BOT@-16>,UCB$_DEVDEPEND+2(R5) ;YES
00B0 C5 D4 0AB4 2093 CLRL UCB$_RECORD(R5)
0092 C5 0F 91 0AB8 2094 CMPB #CDHC_RDP,UCB$_FEX(R5) ; Is this a read reverse?
C1 12 0ABD 2095 BNEQ 100$ ; If NEQ then return NORMAL code
50 0870 8F 3C 0ABF 2096 MOVZWL #SS$_ENDOFFILE,R0 ; Take error return.
BD 11 0AC4 2097 BRB 101$
0AC6 2098 :
0AC6 2099 121$:
07 00 0C E1 0AC6 2100 BBC #MS_XSR0_V_RLL,- ;CHECK IF RECORD LENGTH LONG?
00FE C5 0AC8 2101 UCB$_MS_XSR0(R5),122$ ;TAKE NORMAL RETURN, IF NOT
50 0838 8F 3C 0ACC 2102 MOVZWL #SS$_DATAOVERUN,R0 ;YES, ITS DATAOVERRUN
BD 11 0AD1 2103 BRB 101$ ;TAKE NORMAL RETURN
0AD3 2104 122$:
```



```

      21 00FE C5 0F E1 0AD3 2105      BBC      #MS XSRO_V TMK,-      :CHECK IF SEE TAPE MARK
      46 A5 02 A8 0AD5 2106      UCBSW MS-XSRO(R5),125$      :??
0092 C5 16 91 0AD9 2107      BISW      #<MTSM EOFa-16>,UCBSL_DEVDEPEND+2(R5) ;YES
      16 13 0ADD 2108      CMPB      #CDHC_QTM,UCBSB_FEX(R5) :WAS IT WRITE TMK?
0092 C5 05 91 0AE2 2109      BEQL      125$      :YES, LOOK FOR EOT
      21 13 0AE4 2110      CMPB      #CDHC_STR,UCBSB_FEX(R5) :WAS IT SKIPFILE REVERSE?
0092 C5 02 91 0AE9 2111      BEQL      128$      :YES
      1A 13 0AEB 2112      CMPB      #CDHC_STF,UCBSB_FEX(R5) :WAS IT SKIPFILE FORWARD?
      3C 0AF0 2113      BEQL      128$      :YES
50 0870 8F 3C 0AF2 2114      MOVZWL #SS$_ENDOFFILE,R0      :***NOTE UCBSL RECORD WAS ADJUSTED**
      FF89 31 0AF7 2115      BRW      101$      :SET EOF
      00 E1 0AFA 2116      :      :TAKE NORMAL RETURN
      0C 00FE C5 0F E1 0AFA 2117 125$:      BBC      #MS XSRO_V EOT,-      :CHECK IF AT EOT?
      46 A5 04 A8 0AFC 2118      UCBSW MS-XSRO(R5),128$      :
50 0878 8F 3C 0B00 2119      BISW      #<MTSM EOTa-16>,UCBSL_DEVDEPEND+2(R5) ;YES, SET FLAG
      FF77 31 0B04 2120      MOVZWL #SS$_ENDOFFTAPE,R0      :WRITE ERROR INTO EOT
      FF71 31 0B09 2121      BRW      101$      :
      31 0B0C 2122      :      :
      31 0B0C 2123 128$:      BRW      100$      :ANYTHING ELSE?
      31 0B0F 2124      :      :TAKE NORMAL RETURN**TEMP**
      31 0B0F 2125      :
      31 0B0F 2126      :
      31 0B0F 2127 : FUNCTION REJECT
      31 0B0F 2128 : (BITS OF INTEREST:BOT,WLK,VCK,ONL,ILA,ILC,NEF,WLE)
      31 0B0F 2129 : (TCC=3)
      31 0B0F 2130 :
      31 0B0F 2131 130$:      MOVZWL #SS$_DRVERR,R0      :MARK AS DRIVE ERROR
50 008C 8F 3C 0B14 2132      BBC      #MS XSRO_V BOT,-      :CHECK IF AT BOT
      01 E1 0B16 2133      UCBSW MS-XSRO(R5),132$      :
      08 00FE C5 A8 0B1A 2134      BISW      #<MTSM BOTa-16>,UCBSL_DEVDEPEND+2(R5) ;YES
      46 A5 01 D4 0B1E 2135      CLRL      UCBSL_RECORD(R5)      :
      00B0 C5 0B22 2136 132$:      BBC      #MS XSRO_V VCK,-      :WAS VOLUME CHECK?
      04 E1 0B24 2137      UCBSW MS-XSRO(R5),134$      :
68 A5 1000 8F A8 0B28 2138      BISW      #UCBSM_MS_VCK,UCBSW_DEVSTS(R5) ;YES,RECORD IT
      06 00FE C5 0B2E 2139      :
      08 0B2E 2140 134$:      BBC      #MS XSRO_V WLE,-      :CHECK IF WRITE LOCK ERROR
      09 00FE C5 E1 0B30 2141      UCBSW MS-XSRO(R5),136$      :
      46 A5 08 A8 0B34 2142      BISW      #<MTSM WOLA-16>,UCBSL_DEVDEPEND+2(R5) ;YES, SET FLAG
50 025C 8F 3C 0B38 2143      MOVZWL #SS$_WRITLCK,R0      :MARK AS WRITE-LOCKED ERROR
      06 E0 0B3D 2144      :
      05 0CFE C5 0B3D 2145 136$:      BBS      #MS XSRO_V ONL,-      :CHECK IF ONLINE
      50 01A4 8F 3C 0B3F 2146      UCBSW MS-XSRO(R5),138$      :BR IF YES
      FC34 31 0B43 2147      MOVZWL #SS$_MEDOFFL,R0      :MARK MEDIUM OFFLINE
      31 0B48 2148      :
      31 0B48 2149 138$:      BRW      FATALERR      :TAKE FATAL OR HARD ERROR RETURN
      31 0B4B 2150      :
      31 0B4B 2151      :
      31 0B4B 2152      :
      31 0B4B 2153 : RECOVERABLE ERROR(TAPE MOVED)
      31 0B4B 2154 : RECOVERABLE ERROR(TAPE NOT MOVED)
      31 0B4B 2155 : (TCC=4 OR 5)
      31 0B4B 2156 :
      31 0B4B 2157 :
      31 0B4B 2158 140$:      :
      31 0B4B 2159 :
      31 0B4B 2160 150$:      :
13 009A C5 0F E0 0B4B 2161      BBS      #IOSV_INHRETRY,UCBSW_FUNC(R5),155$ ;IF SET, RETRY INHIBITED
```


TSDRIVER
V04-000

H 6
- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00
HARDWARE COMMAND EXECUTOR 5-SEP-1984 00:18:15 [DRIVER.SRC]TSDRIVER.MAR;1

Page 46
(3)

7E	009C	D5	32	0B51	2162	CVTWL	@UCB\$\$_DPC(R5), -(SP)	;GET BRANCH DISPLACEMENT
009C	C5	8E	C0	0B56	2163	ADDL	(SP)+, @CB\$\$_DPC(R5)	;CALCULATE RETURN ADDRESS -2
009C	C5	02	C0	0B5B	2164	ADDL	#2, UCB\$\$_DPC(R5)	;ADJUST TO CORRECT RETURN ADDRESS
	009C	D5	17	0B60	2165	JMP	@UCB\$\$_DPC(R5)	;RETURN TO DRIVER
				0B64	2166			
	FEFA		31	0B64	2167	155\$: BRW	170\$;RETURN AS FATAL
				0B67	2168			

```
0B67 2170 .SBTTL TS11/TS04 INTERRUPT SERVICE ROUTINE
0B67 2171 :+
0B67 2172 : TS$INT - TS11/TS04 MAGTAPE INTERRUPTS
0B67 2173 :
0B67 2174 : THIS ROUTINE IS ENTERED VIA A JSB INSTRUCTION WHEN AN INTERRUPT OCCURS
0B67 2175 : ON TS11/TS04 CONTROLLER. THE STATE OF THE STACK ON ENTRY IS:
0B67 2176 :
0B67 2177 : 00(SP) = ADDR. OF IDB ADDRESS
0B67 2178 : 04-28(SP) = SAVED R0-R5
0B67 2179 : 32(SP) = INTERRUPT PC
0B67 2180 : 36(SP) = INTERRUPT PSL
0B67 2181 :
0B67 2182 : INTERRUPT DISPATCHING OCCURS AS FOLLOWS:
0B67 2183 :
0B67 2184 : (MUMBLE)
0B67 2185 :
0B67 2186 : -
0B67 2187 :
0B67 2188 TS$INT::
0B67 2189 : MOVL @ (SP)+,R3 ;GET ADDR. OF IDB
0B6A 2190 : MOVQ IDB$L_CSR(R3),R4 ;GET CONTROLLER CSR AND UCB ADDR.
0B6D 2191 : MOVL UCB$L_MS_TSPT1(R5),R0 ;COMMAND PACKET ADDR. IN R0
0B72 2192 : MOVW (R4),UCB$W_MS_TSBA(R5) ;GET DEVICE REGISTER TSBA(TSDB)
0B77 2193 : MOVW 2(R4),UCB$W_MS_TSSR(R5) ;GET TSSR INTO UCB
0B7D 2194 : BBCC #UCB$V_INT,UCB$W_STS(R5),10$ ;IF CLR, INTERRUPT NOT EXPECTED
0B82 2195 : MOVW MS_MHD(R0),UCB$W_MS_MHD(R5) ;SAVE MSG BUFFER IN UCB
0B88 2196 : MOVL MS_LNH(R0),UCB$W_MS_LNH(R5) ;SAVE NEXT LONG WORD
0B8E 2197 : MOVQ MS_XSR0(R0),UCB$W_MS_XSR0(R5) ;SAVE REST OF MSG BUFFER
0B94 2198 : MOVL UCB$L_FR3(R5),R3 ;RESTORE REMAINING DRIVER CONTEXT
0B98 2199 : JSB @UCB$L_FPC(R5) ;CALL DRIVER
0B9B 2200 5$:
0B9B 2201 : MOVQ (SP)+,R0 ;RESTORE REGISTERS
0B9E 2202 : MOVQ (SP)+,R2
0BA1 2203 : MOVQ (SP)+,R4
0BA4 2204 : REI ;RETURN FROM INTERRUPT
0BA5 2205 :
0BA5 2206 :
0BA5 2207 : NON-QIO RESPONSE INTERRUPT
0BA5 2208 :
0BA5 2209 :
0BA5 2210 10$:
02 68 A5 0A E4 0BA5 2211 : BBSC #UCB$V_MS_LBA,UCB$W_DEVSTS(R5),20$ ;YES. LOADING BUFFER ADDR.?
0BA5 2212 : BRB 5$ ; Branch to dismiss interrupt.
0BA5 2213 :
0BA5 2214 :
0BA5 2215 : HERE, WAS LOADING BUFFER ADDRESS
0BA5 2216 :
0BA5 2217 20$:
0BA5 2218 : BBS #MS_TSSR_V_NBA,-
0BA5 2219 : UCB$W_MS_TSSR(R5),5$ ;FAIL TO LOAD BUFFER ADDR.
0BA5 2220 :
0BA5 2221 : BUFFER ADDRESS LOADED SUCCESSFULLY
0BA5 2222 : DO RELEASE MESSAGE BUFFER TO TS11/TS04
0BA5 2223 :
0BA5 2224 30$:
0BA5 2225 :
0BA5 2226 : BISW #<MTSM_BOT@-16>,UCB$L_DEVDEPEND+2(R5) ;**MUST BE AT BOT ;MARK IT
```


- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM^{J 6} DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00 Page 48
TS11/TS04 INTERRUPT SERVICE ROUTINE 5-SEP-1984 00:18:15 [DRIVER.SRC]TSDRIVER.MAR;1 (3)

Address	Op Code	Op Name	Comments
1A 64 A5 05	E1	0BB6	2227 BBC #UCB\$V_POWER,UCB\$W_STS(R5),35\$;BR IF NOT POWERFAIL
15 68 A5 0B	E0	0BBB	2228 BBS #UCB\$V_MS_RPI,UCB\$W_DEVSTS(R5),35\$;BR IF REPOSITION IN PROGRESS
09 68 A5 06	E1	0BC0	2229 BBC #UCB\$V_MS_SWE,UCB\$W_DEVSTS(R5),34\$;BR IF NOT SOFTWARE EMULATION
00F4 C5 00D0 C5	D0	0BC5	2230 MOVL UCB\$L_MS_PMPR(R5),UCB\$L_MS_TPOSITN(R5) ;GET FROM ELSEWHERE
	07	11	2231 BRB 35\$
			2232
00F4 C5 00B0 C5	D0	0BCE	2233 MOVL UCB\$L_RECORD(R5),UCB\$L_MS_TPOSITN(R5) ;SAVE TAPE POSITION
			2234 35\$
			2235
00B0 C5 D4	D4	0BD5	2236 CLRL UCB\$L_RECORD(R5)
			2237 ; WHICH TELL TAPE POSITION
FFBF 31	31	0BD9	2238 BRW 5\$;DO RETURN FROM INTERRUPT
			2239
			2239

```
OBDC 2241 .SBTTL TIMEOUT HANDLER
OBDC 2242 :+MSTMO - HANDLES TIME-OUT WHEN TS11/TS04 DOES NOT INTERRUPT AFTER
OBDC 2243 : A HARDWARE COMMAND ISSUED FOR A SPECIFIED PERIOD OF TIME.
OBDC 2244 : THE ROUTINE DEALLOCATES DATA PATH AND MAP REGISTER IF IT'S DATA
OBDC 2245 : TRANSFER COMMAND, AND ABORTS THE I/O OPERATION.
OBDC 2246 : IF IT WAS DUE TO POWERFAIL, REPOSITIONING IS ATTEMPTED, AND
OBDC 2247 : THE TIME-OUTED IRP IS RE-ISSUED
OBDC 2248 :
OBDC 2249 : INPUT:
OBDC 2250 :
OBDC 2251 : OUTPUT:
OBDC 2252 :
OBDC 2253 :.ENABL LSB ;ENABLE LOCAL SYMBOL
OBDC 2254 MSTMO: SETIPL UCB$B_FIPL(R5) ;LOWER IPL TO DEVICE FORK LEVEL
OBDC 2255 : **ASSUME NO PURGING OF DATAPATH FOR TIMEOUT**
06 68 A5 05 E5 OBEO 2256 BBCC #UCB$V_MS_RDPR,UCB$W_DEVSTS(R5),1$ ;BR IF DATAPATH NOT REQUESTED
OBEO 2257 RELDPR ;RELEASE DATA PATH
OBEB 2258 1$:
OBEB 2259 RELMPR ;RELEASE MAP REGISTERS
04 11 OBF1 2260 BRB 2$
OBF3 2261 :
OBF3 2262 : TIMEOUT FOR NON-I/O XFR OPERATION
OBF3 2263 :
OBF3 2264 :
OBF3 2265 MSTMO1:
OBF3 2266 SETIPL UCB$B_FIPL(R5) ;LOWER IPL TO DEVICE FORK LEVEL
OBF7 2267 2$:
03 05 E4 OBF7 2268 BBSC #UCB$V_POWER,- ; Branch around to reposition if
03 64 A5 OBF9 2269 UCB$W_STS(R5),5$ ; we had POWERFAIL.
00CF 31 OBF9 2270 BRW 90$
OBF9 2271 :
OBF9 2272 : HERE, CHECK DRIVE OFF-LINE UNLOADED OR NOT
OBF9 2273 :
OBF9 2274 :
OBF9 2275 :
OBF9 2276 5$:
F5FE 30 OBF9 2277 BSBW TEST_NBA ; Test to assure we DON'T need TS11
OBF9 2278 ; message buffer address loaded.
03 50 E8 OC02 2279 BLBS P0,6$ ; LBS implies TS11 READY and able.
FB77 31 OC05 2280 BRW FATALERR ; If TS11 not ready, we can't even
OC08 2281 ; try to reposition.
OC08 2282 6$:
50 00000000'GF 16 OC08 2283 JSB G^EXES$READ_TODR ;GET CURRENT TIME OF DAY
000005DC 8F C0 OC0E 2284 ADDL #1500,R0 ;ADD 15 SEC. TO WAIT
7C A5 50 D0 OC15 2285 MOVL R0,UCB$W_BOFF(R5) ;STORE IT IN UCB
OC19 2286 :
OC19 2287 : HERE, GET TS11'S CSR EQUIVALENT INTO R4
OC19 2288 :
OC19 2289 :
OC19 2290 7$:
OC19 2291 DSBINT ;DISABLE INTERRUPTS
OC1F 2292 WFIKPCH 8$,#2 ;WAITFOR INTERRUPT OR TIMEOUT
OC29 2293 IOFORK ;
OC2F 2294 8$:
OC2F 2295 SETIPL UCB$B_FIPL(R5) ;LOWER IPL TO FORK LEVEL
0020 31 OC33 2296 EXHC FAIL,RC_RWD ;DO A REWIND
OC3B 2297 BRW 9$ ;BR IF SUCCESS=>DRIVE ONLINE
```



```
0C3E 2298 FAIL:
0C3E 2299 :
0C3E 2300 : HERE, TO SEND MESSAGE TO OPERATOR TO INFORM DRIVE OFFLINE
0C3E 2301 :
0C3E 2302 :
00000000'GF 16 0C3E 2303 JSB G^EXES$READ TODR ;GET CURRENT TIME OF DAY
7C A5 50 D1 0C44 2304 CMPL RO,UCB$W_B0FF(R5) ;15 SEC. PASSED?
CF 1B 0C48 2305 BLEQU 7$ ;NO , GO TRY AGAIN
0C4A 2306
0C4A 2307
53 54 00'8F 9A 0C4A 2308 MOVZBL #MSG$ DEVOFFLIN,R4 ;SET MESSAGE NUMBER
00000000'GF 9E 0C4E 2309 MOVAB G^SYS$GL OPRMBX,R3 ;GET ADDRESS OF OPERATOR MAILBOX
00000000'GF 16 0C55 2310 JSB G^EXES$NDEVMSG ;SEND MESSAGE TO OPERATOR
FFAA 31 0C5B 2311 BRW 6$ ;
0C5E 2312 :
0C5E 2313 :
0C5E 2314 : OTHERWISE DO REPOSITIONING TAPE
0C5E 2315 :
0C5E 2316 9$:
68 A5 0800 8F A8 0C5E 2317 BISW #UCB$M_MS_RPI,UCB$W_DEVSTS(R5) ;FLAG REPOSITION IN PROGRESS
EXHC 50$,HC_RWD ;DO REWIND 1ST
0C64 2318 ; & CLEAR UCB$L_RECORD
0C6C 2319
0C6C 2320 10$:
00F4 C5 00B0 C5 D1 0C6C 2321 CMPL UCB$L_RECORD(R5),UCB$L_MS_TPOSITN(R5) ;CHECK REPOSITIONING
46 13 0C73 2322 BEQL 80$ ;BR IF YES
00F4 C5 00B0 C5 D1 0C75 2323 CMPL UCB$L_RECORD(R5),UCB$L_MS_TPOSITN(R5) ;IS IT GTR THAN
33 14 0C7C 2324 BGTR 50$ ;BR IF YES
50 00F4 C5 00B0 C5 C3 0C7E 2325 SUBL3 UCB$L_RECORD(R5),UCB$L_MS_TPOSITN(R5),RO ;GET WHAT'S LEFT
50 00007FFF 8F D1 0C86 2326 CMPL #^X7FFF,RO ;LESS THAN 32,768?
09 14 0C8D 2327 BGTR 20$ ;BR IF YES
00B4 C5 7FFF 8F B0 0C8F 2328 MOVW #^X7FFF,UCB$W_MS_SPACNT(R5) ;SKIP 32,768 RECORDS TILL DONE
05 11 0C96 2329 BRB 30$ ;
0C98 2330 20$:
00B4 C5 50 B0 0C98 2331 MOVW RO,UCB$W_MS_SPACNT(R5) ;SKIP WHAT'S LEFT
0C9D 2332 30$:
51 00C4 C5 3C 0CA5 2333 EXHC 50$,HC_SRF ;
00B0 C5 51 C0 0CAA 2334 MOVZWL UCB$W_MS_XC(R5),R1 ;GET NO. OF RECORDS PASSED
BB 11 0CAF 2335 ADDL R1,UCB$L_RECORD(R5) ;UPDATE TAPE POSITION
0CB1 2336 BRB 10$ ;GO BACK
68 A5 0800 8F AA 0CB1 2337 50$:
FABF CF 17 0CB7 2338 BICW #UCB$M_MS_RPI,UCB$W_DEVSTS(R5) ;CLEAR FLAG, REPOSI. FAILED
0CBB 2339 JMP FATALERO ;
0CBB 2340 :
0CBB 2341 : HERE, GO AHEAD WITH THE CURRENT QIO
0CBB 2342 :
0CBB 2343 80$:
68 A5 0800 8F AA 0CBB 2344 BICW #UCB$M_MS_RPI,UCB$W_DEVSTS(R5) ;CLEAR FLAG, REPOSITION DONE
53 58 A5 D0 OCC1 2345 MOVL UCB$L_IRP(R5),R3 ;R3 HAS IRP ADDRESS
78 A5 2C A3 7D OCC5 2346 MOVQ IRP$L_SVAPTE(R3),UCB$L_SVAPTE(R5) ;RESTORE XFER PARAMETERS
F5F3 CF 17 OCCA 2347 JMP TS_STARTIO
0CCE 2348 90$:
00000000'GF 16 0CCE 2349 JSB G^ERL$DEVICTMO ;LOG TIMEOUT ERROR
50 022C 8F 3C OCD4 2350 MOVZWL #SS$_TIMEOUT,RO ;SET TIMEOUT STATUS
OCD9 2351 .IF TS TRACE
OCD9 2352 BSBW TRACE_STATUS ; Trace final I/O status.
OCD9 2353 .ENDC
OCD9 2354 REQCOM ;GO COMPLETE I/O REQUEST PROCESSING
```

TSDRIVER
V04-000

- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00 Page 51
TIMEOUT HANDLER 5-SEP-1984 00:18:15 [DRIVER.SRC]TSDRIVER.MAR;1 (3)

OCDF 2355
OCDF 2356

.DSABL LSB


```
OCDF 2358 .SBTTL TS11/TS04 REGISTER DUMP ROUTINE
OCDF 2359 :+
OCDF 2360 : TS_REGDUMP - TS11/TS04 REGISTER DUMP ROUTINE
OCDF 2361 :
OCDF 2362 : THIS ROUTINE IS CALLED TO SAVE THE CONTROLLER AND DRIVE REGISTERS IN A
OCDF 2363 : SPECIFIED BUFFER. IT IS CALLED FROM THE DEVICE ERRORLOGGING ROUTINE AND
OCDF 2364 : FROM THE DIAGNOSTIC BUFFER FILL ROUTINE
OCDF 2365 :
OCDF 2366 : INPUT:
OCDF 2367 : R0 = ADDRESS OF REGISTER SAVE BUFFER
OCDF 2368 : R4 = ADDRESS OF CSR (EQUIVALENT)
OCDF 2369 : R5 = UCB ADDRESS
OCDF 2370 :
OCDF 2371 : OUTPUT:
OCDF 2372 :
OCDF 2373 : THE CONTROLLER AND DRIVE REGISTERS ARE SAVED IN THE SPECIFIED BUFFER
OCDF 2374 : -
OCDF 2375 :
OCDF 2376 TS_REGDUMP:
80      80      17      DO OCDF 2377      MOVL      #23,(R0)+      ;23 REGISTERS FOLLOW TO BE DUMPED
80      00C0 C5      3C OCDF 2378      MOVZWL     UCB$W_MS_TSBA(R5),(R0)+ ;GET TSBA
80      00C2 C5      3C OCDF 2379      MOVZWL     UCB$W_MS_TSSR(R5),(R0)+ ;GET TSSR
80      00C6 C5      9A OCDF 2380      MOVZBL     UCB$B_MS_DPN(R5),(R0)+ ;GET DATAPATH NO.
80      00C8 C5      DO OCDF 2381      MOVL      UCB$L_MS_DPR(R5),(R0)+ ;GET DATAPATH REG.
80      00CC C5      DO OCDF 2382      MOVL      UCB$L_MS_FMPR(R5),(R0)+ ;GET FINAL MAP REGISTER
80      00D0 C5      DO OCDF 2383      MOVL      UCB$L_MS_PMPR(R5),(R0)+ ;GET FINAL-1 MAP REGISTER
80      00D4 C5      DO OCDF 2384      MOVL      UCB$L_MS_NMPR(R5),(R0)+ ;GET FINAL+1 MAP REGISTER
51      00B6 C5      DO OCDF 2385      MOVL      UCB$L_MS_TSPT1(R5),R1 ;GET MESSAGE BUFFER ADDR
52      0F      9A OCDF 2386      MOVZBL     #15,R2      ;15 WORDS IN MSG BUFFER
80      80      81      3C OCDF 2387      MOVZWL     (R1)+,(R0)+      ;COPY FROM MSG BUFFER
80      FA 52      F5 OCDF 2388      ;**FROM MS_CPHD TO MS_XSR3, SEE $DEFINI MS**
80      00C7 C5      9A OCDF 2389      SOBGTR     R2,10$      ;LOOP BACK
80      05      9A OCDF 2390      MOVZBL     UCB$B_MS_PER(R5),(R0)+ ;GET PURGE ERROR INDICATOR
80      05      05 OCDF 2391      RSB
80      05      05 OCDF 2392
80      05      05 OCDF 2393
80      05      05 OCDF 2394 TS_END:      ;ADDRESS OF LAST LOCATION IN DRIVER
80      05      05 OCDF 2395
80      05      05 OCDF 2396 .END
```


TSDRIVER
Symbol table

B 7

- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00
5-SEP-1984 00:18:15 [DRIVER.SRC]TSDRIVER.MAR;1

Page 53
(3)

\$\$\$
\$\$GP
ACPSACCESS
ACPSDEACCESS
ACPSMODIFY
ACPSMOUNT
ACPSREADBLK
ACPSWRITEBLK
ATS_UBA
CDHC_BRL
CDHC_CLN
CDHC_DRI
CDHC_ERS
CDHC_GST
CDHC_NOP
CDHC_PAK
CDHC_RDN
CDHC_RDP
CDHC_RPS
CDHC_RRN
CDHC_RRP
CDHC_RWD
CDHC_SCH
CDHC_SRF
CDHC_SRR
CDHC_STF
CDHC_STR
CDHC_UNL
CDHC_WCK
CDHC_WDR
CDHC_WKR
CDHC_WRC
CDHC_WRD
CDHC_WSM
CDHC_WTM
CDHC_WTR
CLEAN
CLS_MDE
CLS_MDF
CLS_ONF
CLS_OTHER
CLS_PTB
CLS_WLN
CRBSL_INTD
DCS_TAPE
DDBSL_ACPD
DDBSL_DDT
DEVSM_AVL
DEVSM_DIR
DEVSM_ELG
DEVSM_FOD
DEVSM_IDV
DEVSM_NNM
DEVSM_ODV
DEVSM_SDI
DEVSM_SQD
DEVSV_FOR

= 00000020 R 02
= 00000002
***** X 03
***** X 03
***** X 03
***** X 03
***** X 03
***** X 03
= 00000001
= 00000019
= 00000018
= 00000004
= 00000006
= 00000015
= 00000000
= 00000008
= 0000000C
= 0000000F
= 00000013
= 00000010
= 00000011
= 00000003
= 00000014
= 00000009
= 00000007
= 00000002
= 00000005
= 00000001
= 0000000A
= 00000012
= 0000000D
= 0000001B
= 0000000E
= 0000001A
= 00000016
= 00000017
= 00000711 R 03
= 00000003
= 00000001
= 00000000
= 00000001
= 00000000
= 00000002
= 00000024
= 00000002
= 00000010
= 0000000C
= 00040000
= 00000008
= 00400000
= 00004000
= 04000000
= 00000200
= 08000000
= 00000010
= 00000020
= 00000018

DEVSV_MNT
DPTSC_LENGTH
DPTSC_VERSION
DPT\$INITAB
DPT\$REINITAB
DPT\$TAB
DRVCLR
DTS_TS11
DYN\$C_CRB
DYN\$C_DDB
DYN\$C_DPT
DYN\$C_UCB
EMBSL_DV_REGSAV
ERASE
ERL\$DEVICERR
ERL\$DEVICTMO
EXESALONONPAGED
EXESGL_NONPAGED
EXESIOFORK
EXESONEPARM
EXESREAD_TODR
EXESSETMODE
EXESSNDEVMSG
EXESZEROPARM
FAIL
FATALERO
FATALERR
FCC_CPE
FCC_IDF
FCC_LAP
FCC_UPE
FCNEXT
FDISPATCH
FUNCTAB_LEN
GETSTS
HCEX
HCTAB
HC_BRL
HC_CLN
HC_DRI
HC_ERS
HC_GST
HC_NOP
HC_PAK
HC_RDN
HC_RDP
HC_RPS
HC_RRN
HC_RRP
HC_RWD
HC_SCH
HC_SRF
HC_SRR
HC_STF
HC_STR
HC_UNL
HC_WCK

= 00000013
= 00000038
= 00000004
00000038 R 02
00000076 R 02
00000000 R 02
0000071C R 03
= 00000004
= 00000005
= 00000006
= 0000001E
= 00000010
= 0000004E
000006F0 R 03
***** X 03
***** X 03
***** X 03
***** X 03
***** X 03
***** X 03
***** X 03
***** X 03
***** X 03
***** X 03
00000C3E R 03
0000077A R 03
0000077F R 03
= 00000001
= 00000000
= 00000003
= 00000002
00000795 R 03
00000379 R 03
= 00000088
00000727 R 03
000007EF R 03
00000038 R 03
= 0000C08A
= 0000C28A
= 0000C08B
= 0000C189
= 0000C08F
= 00000000
= 00000000
= 0000C081
= 0000C181
= 00000000
= 0000C381
= 0000C281
= 0000C488
= 00000000
= 0000C088
= 0000C188
= 0000C088
= 0000C188
= 0000C18A
= 00000000

TSDRIVER
Symbol table

- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00
5-SEP-1984 00:18:15 [DRIVER.SRC]TSDRIVER.MAR;1

Page 54
(3)

HC_WDR	= 0000C285	IOCSLOADUBAMAPA	*****	X	03
HC_WKR	= 00000000	IOCSMNTVER	*****	X	03
HC_WRC	= 0000C084	IOCSPURGDATAP	*****	X	03
HC_WRD	= 0000C085	IOCSRELDATAP	*****	X	03
HC_WSM	= 0000C086	IOCSRELMAPREG	*****	X	03
HC_WTM	= 0000C089	IOCSREQCOM	*****	X	03
HC_WTR	= 0000C289	IOCSREQDATAP	*****	X	03
IDBSL_CSR	= 00000000	IOCSREQMAPREG	*****	X	03
IDBSL_OWNER	= 00000004	IOCSRETURN	*****	X	03
IOSM_NOWAIT	= 00000080	IOCSWFIKPC	*****	X	03
IOSV_INHRETRY	= 0000000F	IRPSL_MEDIA	= 00000038		
IOSV_OPPOSITE	= 00000009	IRPSL_SVAPTE	= 0000002C		
IOSV_REVERSE	= 00000006	IRPSL_WIND	= 00000018		
IOSV_SWAP	= 00000008	IRPSS_FCODE	= 00000006		
IOS_ACCESS	= 00000032	IRPSV_FCODE	= 00000000		
IOS_ACPCONTROL	= 00000038	IRPSV_PHYSIO	= 00000008		
IOS_AVAILABLE	= 00000011	IRPSV_VIRTUAL	= 00000004		
IOS_CLEAN	= 0000001E	IRPSW_FUNC	= 00000020		
IOS_CREATE	= 00000033	IRPSW_STS	= 0000002A		
IOS_DEACCESS	= 00000034	LDTSD	000008EB	R	03
IOS_DELETE	= 00000035	MASKH	= 00000008		
IOS_DRVCLR	= 00000004	MASKL	= 04000000		
IOS_ERASETAPE	= 00000006	MEDIA_ID_TS11	= 6CE9300B		
IOS_MODIFY	= 00000036	MMGSGC_SPTBASE	*****	X	03
IOS_MOUNT	= 00000039	MSSDDT	00000000	RG	03
IOS_NOP	= 00000000	MSG\$ DEVOFFLIN	*****	X	03
IOS_PACKACK	= 00000008	MSGREL	000006FB	R	03
IOS_READBLK	= 00000021	MSG_ATN	= 00000013		
IOS_READPBLK	= 0000000C	MSG_END	= 00000010		
IOS_READPRESET	= 00000019	MSG_ERR	= 00000012		
IOS_READVBLK	= 00000031	MSG_FAL	= 00000011		
IOS_RECAL	= 00000003	MSG_LOG	= 00000014		
IOS_REREADN	= 00000016	MSTMO	00000BDC	R	03
IOS_REREADP	= 00000017	MSTM01	00000BF3	R	03
IOS_REWIND	= 00000024	MS_BA1	00000004		
IOS_REWINDOFF	= 00000022	MS_BACT	00000002		
IOS_SENSECHAR	= 0000001B	MS_CHWD	0000000E		
IOS_SENSEMODE	= 00000027	MS_CNT	00000006		
IOS_SETCHAR	= 0000001A	MS_CPHD	00000000		
IOS_SETMODE	= 00000023	MS_CPHD_M_ACK	= 00008000		
IOS_SKIPFILE	= 00000025	MS_CPHD_M_CVC	= 00004000		
IOS_SKIPRECORD	= 00000026	MS_CPHD_M_IE	= 00000080		
IOS_SPACEFILE	= 00000002	MS_CPHD_M_OPP	= 00002000		
IOS_SPACE RECORD	= 00000009	MS_CPHD_M_SWB	= 00001000		
IOS_UNLOAD	= 00000001	MS_LNH	00000012		
IOS_VIRTUAL	= 0000003F	MS_LNTH	0000000C		
IOS_WRITECHECK	= 0000000A	MS_MBA0	00000008		
IOS_WRITEBLK	= 00000020	MS_MBA1	0000000A		
IOS_WRITE MARK	= 0000001C	MS_MHD	00000010		
IOS_WRITEOF	= 00000028	MS_RBPC	00000014		
IOS_WRITEPBLK	= 0000000B	MS_TSSR_S_TCC	= 00000003		
IOS_WRITERET	= 00000018	MS_TSSR_V_NBA	= 0000000A		
IOS_WRITEVBLK	= 00000030	MS_TSSR_V_SSR	= 00000007		
IOS_WRTTMKR	= 0000001D	MS_TSSR_V_TCC	= 00000001		
IO\$CANCELIO	*****	MS_XSRO	00000016		
IO\$DIAGBUFILE	*****	MS_XSRO_V_BOT	= 00000001		
IO\$LOADUBAMAP	*****	MS_XSRO_V_EOT	= 00000000		

Variable	Value	Unit	Value
SSS_VOLINV	=	00000254	
SSS_WRITLCK	=	0000025C	
SYSSGL_OPRMBX		*****	X 03
TCC_ATN	=	00000001	
TCC_FNR	=	00000003	
TCC_FTL	=	00000007	
TCC_NML	=	00000000	
TCC_REM	=	00000004	
TCC_REN	=	00000005	
TCC_TSA	=	00000002	
TCC_UER	=	00000006	
TEST_NBA		00000200	R 03
TSSINT		00000B67	RG 03
TS_END		00000D19	R 03
TS_FUNCABLE		00000070	R 03
TS_INIT		000000F8	R 03
TS_REGDUMP		00000CDF	R 03
TS_STARTIO		000002C1	R 03
UCBSB_CEX	=	00000093	
UCBSB_DEVCLASS	=	00000040	
UCBSB_DEVTYP	=	00000041	
UCBSB_DIPL	=	0000005E	
UCBSB_ERTCNT	=	00000080	
UCBSB_ERTMAX	=	00000081	
UCBSB_FEX	=	00000092	
UCBSB_FIPL	=	0000000B	
UCBSB_MS_DPN		000000C6	
UCBSB_MS_PER		000000C7	
UCBSK_LCC_TAPE_LENGTH	=	000000B4	
UCBSK_MS_LENGTH	=	00000106	
UCBSL_CRB	=	00000024	
UCBSL_DEVCHAR	=	00000038	
UCBSL_DEVCHAR2	=	0000003C	
UCBSL_DEVDEPEND	=	00000044	
UCBSL_DPC	=	0000009C	
UCBSL_FPC	=	0000000C	
UCBSL_FR3	=	00000010	
UCBSL_IOQFL	=	0000004C	
UCBSL_IRP	=	00000058	
UCBSL_MEDIA_ID	=	0000008C	
UCBSL_MS_DPR		000000C8	
UCBSL_MS_FMPR		000000CC	
UCBSL_MS_NMPR		000000D4	
UCBSL_MS_OMPR		000000D8	
UCBSL_MS_PMPR		000000D0	
UCBSL_MS_TIMEOUT		000000DC	
UCBSL_MS_TMP2		000000E8	
UCBSL_MS_TPOSITN		000000F4	
UCBSL_MS_TSPT1		000000B6	
UCBSL_MS_TSPT2		000000BA	
UCBSL_RECORD	=	000000B0	
UCBSL_SVAPTE	=	00000078	
UCBSL_VCB	=	00000034	
UCBSM_MS_FEF	=	00000001	
UCBSM_MS_LBA	=	00000400	
UCBSM_MS_RDPR	=	00000020	
UCBSM_MS_RPI	=	00000800	

TSDRIVER
Symbol table

- VAX/VMS TS11/TS04 MAGTAPE SUBSYSTEM DR 16-SEP-1984 00:10:52 VAX/VMS Macro V04-00 Page 56
5-SEP-1984 00:18:15 [DRIVER.SRC]TSDRIVER.MAR;1 (3)

UCBSM_MS_SWAP	=	00000002		
UCBSM_MS_SWE	=	00000040		
UCBSM_MS_VCK	=	00001000		
UCBSM_ONLINE	=	00000010		
UCBSM_VALID	=	00000800		
UCBSQ_MS_BUF SVAPTE		000000EC		
UCBSQ_MS_TMP1		000000E0		
UCBSV_INT	=	00000001		
UCBSV_MS_FEF	=	00000000		
UCBSV_MS_LBA	=	0000000A		
UCBSV_MS_RDPR	=	00000005		
UCBSV_MS_RPI	=	0000000B		
UCBSV_MS_SWAP	=	00000001		
UCBSV_MS_SWE	=	00000006		
UCBSV_MS_VCK	=	0000000C		
UCBSV_POWER	=	00000005		
UCBSV_VALID	=	0000000B		
UCBSW_BCNT	=	0000007E		
UCBSW_BOFF	=	0000007C		
UCBSW_DEVBUSIZ	=	00000042		
UCBSW_DEVSTS	=	00000068		
UCBSW_FUNC	=	0000009A		
UCBSW_MS_LNH		000000FA		
UCBSW_MS_MHD		000000F8		
UCBSW_MS_RBPC		000000FC		
UCBSW_MS_SPACNT		000000B4		
UCBSW_MS_TSBA		000000C0		
UCBSW_MS_TSPT3		000000BE		
UCBSW_MS_TSSR		000000C2		
UCBSW_MS_XC		000000C4		
UCBSW_MS_XSR0		000000FE		
UCBSW_MS_XSR1		00000100		
UCBSW_MS_XSR2		00000102		
UCBSW_MS_XSR3		00000104		
UCBSW_STS	=	00000064		
UNLOAD		00000706	R	03
VASS_VPN	=	00000015		
VASV_VPN	=	00000009		
VECSB_DATAPATH	=	00000013		
VECSL_IDB	=	00000008		
VECSL_UNITINIT	=	00000018		
VECSW_MAPREG	=	00000010		
WCBSW_NMAP	=	00000016		
WRITECHAR		00000507	R	03
WRITECHECK		000003F1	R	03
WRITECHECKR		000003F1	R	03
WRITEDATA		000004A4	R	03
WRITERET		000004F1	R	03
WRITESUBS		000004FC	R	03
WRTTMK		00000698	R	03
WRTTMKR		000006E5	R	03
XTC		00000A2F	R	03
XTC1		00000A3C	R	03

+-----+
! Psect synopsis !
+-----+

PSECT name	Allocation	PSECT No.	Attributes
. ABS .	00000000 (0.)	00 (0.)	NOPIC USR CON ABS LCL NOSHR NOEXE NORD NOWRT NOVEC BYTE
\$AB\$\$	00000106 (262.)	01 (1.)	NOPIC USR CON ABS LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$105_PROLOGUE	00000086 (134.)	02 (2.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$115_DRIVER	00000D19 (3353.)	03 (3.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC LONG

+-----+
! Performance indicators !
+-----+

Phase	Page faults	CPU Time	Elapsed Time
Initialization	33	00:00:00.05	00:00:01.89
Command processing	120	00:00:00.39	00:00:03.56
Pass 1	655	00:00:22.16	00:01:14.43
Symbol table sort	0	00:00:02.80	00:00:14.50
Pass 2	410	00:00:05.50	00:00:22.91
Symbol table output	1	00:00:00.21	00:00:00.60
Psect synopsis output	0	00:00:00.01	00:00:00.01
Cross-reference output	0	00:00:00.00	00:00:00.00
Assembler run totals	1221	00:00:31.12	00:01:57.91

The working set limit was 2550 pages.
180605 bytes (353 pages) of virtual memory were used to buffer the intermediate code.
There were 140 pages of symbol table space allocated to hold 2533 non-local and 147 local symbols.
2396 source lines were read in Pass 1, producing 27 object records in Pass 2.
51 pages of virtual memory were used to define 49 macros.

+-----+
! Macro library statistics !
+-----+

Macro library name	Macros defined
_\$255\$DUA28:[SYS.OBJ]LIB.MLB;1	32
-\$255\$DUA28:[SYSLIB]STARLET.MLB;2	12
TOTALS (all libraries)	44

2529 GETS were required to define 44 macros.

There were no errors, warnings or information messages.

MACRO/LIS=LISS:TSDRIVER/OBJ=OBJ:TSDRIVER MSRC\$:TSDRIVER/UPDATE=(ENH\$:TSDRIVER)+EXECMLS/LIB

0117 AH-BT13A-SE
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION
CONFIDENTIAL AND PROPRIETARY

